

TA-ETTES/ETTES/ES

SERVICE MANUAL

E Model
TA-E77ES

US Model
Canadian Model
AEP Model
UK Model
TA-E77ESD



Photo: TA-E77ESD

SPECIFICATIONS

AUDIO SPECIFICATIONS

Item	Condition			Data
Total harmonic distortion	At rated 20Hz – 20kHz output			0.001%
Intermodulation (M)distortion 60Hz:7kHz = 4:1	at rated output			0.001%
Residual noise	Network A			Less than 10 μ V
Frequency response	PHONO MM			RIAA equalization curve ± 0.2 dB
	TUNER, CD, VIDEO 1, 2, 3 TAPE 1, 2, AUX, ADAPTOR IN			3Hz – 300kHz $^{+0}_{-3}$ dB
Input sensitivity	PHONO	MC	3 ohms	0.17mV, 100 ohms
			40 ohms	0.17mV, 1k ohm
	MM			2.5mV, 50k ohms
	TUNER, CD, AUX, TAPE 1, 2, VIDEO 1, 2, 3 ADAPTOR IN			150mV, 50k ohms
Maximum input capability (1kHz)	PHONO (1 kHz, THD 0.003%)	MC		9mV
		MM		150mV
S/N (network)	PHONO	MC (0.5mV)		83dB(A)
		MM (5mV)		95dB(A)
	TUNER, CD, AUX, TAPE 1, 2, VIDEO 1, 2, 3 ADAPTOR IN			105dB (A)

Item	Condition	Data
Output voltage impedance	REC OUT 1, 2, VIDEO OUT, ADAPTOR OUT, DAT OUT (TA-E77ESD)	150mV, 1k ohm
HEADPHONES	45 milliwatts (at 8 ohms) Accepts low and high impedance headphones.	
PRE OUT	1.5V, 47 ohms G-AEP model : 1.5V 20 ohms	
Tone controls	BASS, at 100Hz	$+3.5_{-4}$ dB (turnover freq. 200Hz) $+7_{-6}$ dB (turnover freq. 400Hz)
	TREBLE, at 10kHz	$+7_{-7.5}$ dB (turnover freq. 3kHz) ± 3.5 dB (turnover freq. 5kHz)
SUBSONIC filter	—	6 dB/octave attenuation below 15Hz

— Continued on Page 2 —

STEREO CONTROL AMPLIFIER
SONY[®]



AUD

TA-E77ES/E77ESD

VIDEO SPECIFICATIONS

INPUT	VIDEO 1, 2, 3	Voltage 1Vp-p Impedance 75 ohms
OUTPUT	VIDEO 1, 2 MONITOR TV	Voltage 1Vp-p Impedance 75 ohms
S VIDEO IN (TA-E77ESD only) Luminance signal	VIDEO 1, 2	Voltage 1Vp-p Impedance 75 ohms
Chroma signal	VIDEO 1, 2	Voltage 0.286Vp-p Impedance 75 ohms
S VIDEO OUT (TA-E77ESD only) Luminance signal	VIDEO 1 MONITOR	Voltage 1Vp-p Impedance 75 ohms
Chroma signal	VIDEO 1 MONITOR	Voltage 0.286Vp-p Impedance 75 ohms

DIGITAL SPECIFICATIONS (TA-E77ESD only)

Converter section

Digital input (phono jacks)	Input level (sensitivity) 0.5 Vp-p $\pm 20\%$	Impedance 75 ohms
Digital output	Output level (voltage) 0.5Vp-p $\pm 20\%$	Impedance 75 ohms The input signal comes unprocessed to the digital output terminals via a buffer, only when the TA-E77ESD is operating.

Number of channels

2 (stereo)

Demodulation (D/A conversion)

16-bit linear

Frequency response

5Hz – 20kHz $\pm 0.5\text{dB}$

(Input digital signal sampling freq. 44.1kHz)

Harmonic distortion

Less than 0.004% at 1kHz

(Input digital signal sampling freq. 44.1kHz)

16-bit operation)

Dynamic range

More than 95dB

(Input digital signal sampling freq. 44.1kHz)

16-bit operation)

Channel separation

More than 90dB

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY SHADING AND MARK
⚠ ON THE SCHEMATIC DIAGRAMS AND IN THE
PARTS LIST ARE CRITICAL TO SAFE OPERATION.
REPLACE THESE COMPONENTS WITH SONY PARTS
WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS
MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ!

LES COMPOSANTS IDENTIFIÉS PAR UNE TRAME ET
UNE MARQUE ⚠ SUR LES DIAGRAMMES SCHÉ-
MATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES
POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REM-
PLACER CES COMPOSANTS QUE PAR DES PIÈCES
SONY DONT LES NUMÉROS SONT DONNÉS DANS CE
MANUEL OU DANS LES SUPPLÉMENTS PUBLIÉS PAR
SONY.

GENERAL

System Low-noise FET high gain, NFB type equalizer amplifier, low noise FET, Double-stage differential, push-pull output, flat amplifier passive type direct tone control

Power requirements

US, Canadian model: 120V AC, 60Hz

AEP, UK, E model: 110–120V or 220–240V AC adjustable, 50/60Hz

G-AEP model: 220–240V AC, 50/60Hz

Power consumption: 30W

AC outlets

US, Canadian, E model: 1 switched, 400W max.
1 unswitched, 400W max.

AEP, UK, G-AEP model: 1 switched, 400W max.

Dimensions Approx. 470 x 130 x 370mm (w/h/d)
(18 $\frac{1}{2}$ x 5 $\frac{1}{4}$ x 14 $\frac{1}{2}$ inches)
incl. projecting parts and controls

Weight Approx. 12.1kg (26lb 11oz): TA-E77ES
Approx. 13kg (28lb 11oz): TA-EE7ESD

Supplied accessory

US, Canadian model: Programmable commander RM-E7 (1),
Digital signal cord (1), Connecting cord (1),
Sony New Super batteries (4), Index sheet

AEP, UK, G-AEP model: Remote commander RM-177D (1),
Digital signal cord (1), Connecting cord (1),
Sony New Super batteries (2)

E model: Remote commander RM-177 (1), Connecting cord (1), Sony New Super batteries (2)

FEATURES

Higher sound quality

Sony performed numerous experiments and trials to determine the best chassis structure for an amplifier capable of top quality sound reproduction with superb dynamics, response and presence. The results provided the basis for the TA-E77ES/E77ESD's chassis design. The chassis, named "Gibraltar", is solid as a rock to avoid internal vibrations caused by power transformers, power transistors, and other amplifier components and stress from the outside caused by floor vibration from speakers, home appliances, and other sources. Additionally, the chassis is made of non-magnetic and non-conducting materials and this eliminates magnetic hysteresis distortion caused by transformers, capacitors, transistors, etc.

Abundant functions

- Audio input selectors control 7 audio and 3 video signals.
- Input source selection can be remotely controlled by the supplied remote commander.
- TA-E77ESD provides digital input and output jacks. These deliver excellent sound reproduction with digital audio equipment.

For the model in USA and Canada only, a programmable commander is supplied. This can remotely control almost any Sony audio and video equipment. Further, it can "read" and "store" the functions of another remote commander using an infrared ray transmitter, not only those made by Sony but those of other manufacturers as well. With this single commander, you can control your audio and video equipment regardless of their manufacturers.

SAFETY CHECK-OUT

After correcting the original service problem, perform the following safety check before releasing the set to the customer:

Check the antenna terminals, metal trim, "metallized" knobs, screws, and all other exposed metal parts for AC leakage. Check leakage as described below.

LEAKAGE TEST

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5 mA (500 microamperes). Leakage current can be measured by any one of three methods.

1. A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instruments.
2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 0.75 V, so analog meters must have an accurate low-voltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOM that is suitable. Nearly all battery operated digital multimeters that have a 2V AC range are suitable. (See Fig. A)

TABLE OF CONTENTS

<u>Title</u>	<u>Description</u>	<u>Page</u>
Specifications	1
Features	2
Safety Check-out (US Model)	3
Troubleshooting guide	4
Function of Controls (TA-E77ES)	5
Function of Controls (TA-E77ESD)	6
Overall connection diagram	7
Function of Controls (RM-E7)	8
Function of Controls (RM-177/177D)	10
How to use learning function (RM-E7)	11
Disassembly and Assembly for		
Switch Section	12
Section 1. Adjustment	13
Section 2. Diagrams		
2-1. Mounting Diagram (1)	D/A Converter Section (TA-E77ESD)	15
2-2. Schematic Diagram (1)	D/A Converter Section (TA-E77ESD)	17
2-3. Mounting Diagram (2)	Control AMP Section	22
2-4. Schematic Diagram (2)	Control AMP Section	27
Section 3. Exploded Views and Parts List	33
Section 4. Electrical Parts List	37





Fig. A. Using an AC voltmeter to check AC leakage.

Troubleshooting guide

Trouble	Cause/Remedy
No audio	Faulty setting of OUTPUT selector. Faulty connection • Connect the power amplifier and other equipments correctly. The audio input selector is not correctly set. The ADAPTOR switch is set to on when the ADAPTOR jacks are not used. The equipment connected to the ADAPTOR jacks is not turned on. • Set the ADAPTOR switch to off or turn on the equipment.
No audio from one channel or unbalanced left and right sound level	Incorrect setting of the BALANCE control
No recording	The AUDIO REC SELECTORs are not correctly set. • Set the selectors correctly. For selection on right AUDIO REC SELECTOR, set the left selector to the right most position.
Low volume	The MUTIG switch is depressed. • Release the switch. Incorrect setting of the CARTRIDGE load selector.
Lack of bass sound or obscure instrument position	Mal-setting of sound quality controls • Adjust the controls for sound quality. Faulty setting of the CARTRIDGE load selector.
Severe hum or noise	Noise from TV, etc. • Keep the connecting cords away from transformers or motors, TV and fluorescent lights. Faulty connection of turntable system. • Ground the turntable system
Remote control operation cannot be performed.	The batteries in the commander are exhausted. • Replace them with new ones.

FUNCTION OF CONTROLS

TA-E77ES



TA-E77ESD

SAMPLING FREQ. (DIGITAL) indicators

Lights up according to the input digital signal.

MUTING -20dB switch and indicator

Audio input selectors and indicators

ADAPTOR switch and indicator

Remote sensor

SOURCE DIRECT switch and indicator

POWER switch

ATTENUATOR knob and indicator



HEADPHONES jack (stereo phone jack)

BALANCE control

OUTPUT selector

MODE selector

TURNOVER frequency selector

SUBSONIC filter switch


BASS and TREBLE controls

CARTRIDGE load selector


TURNOVER frequency selector

AUDIO REC (recording output) SELECTOR

Overall connection diagram



Programmable commander RM-E7

**1** AUDIO POWER ON/OFF switch

Turns the power of the amplifier on or off.

2 SYSTEM POWER OFF switch

Turns off the power of the amplifier, TV, VTR1 or VTR2.

3 VIDEO POWER ON/OFF switch

TV: Turns the power of the TV on or off.

VTR1: Turns the power of the VTR 1 on or off.

VTR2: Turns the power of the VTR 2 on or off.

4 PHONO buttons

▼ ▼: Lifts or lowers the tonearm.

►: Starts record playing

■: Stops record playing

5 CD buttons

◀◀/▶▶: AMS*

►: Starts playing

■: Stops playing

*AMS = Automatic Music Sensor

6 DAT buttons

◀◀/▶▶: Leftward and rightward fast winding

►: Forward play

■: Stop

◀◀/▶▶: AMS

■: Pause

○: Record

7 TAPE button

◀: Leftward fast winding

◀: Reverse play

►: Forward play

▶: Rightward fast winding

■: Stop

■: Pause

○: Record muting

●: Recording

8 Program source selectors**9** ADAPTOR switch**10** SOURCE DIRECT switch

11 MUTING switch**12 ATTENUATOR buttons****13 TUNER PRESET buttons**

+ : Selects higher preset number.
- : Selects lower preset number.

14 Indicators

LEARNED
Transmit indicator
READY

15 LEARN/USER/SONY selector

Selects the function of the FREE buttons or the other buttons.
SONY: To operates this commander normally.
LEARN: To memorize the function of another remote commander on one of the FREE buttons.
USER: To recall the memorized function on FREE buttons.

16 FM-AM/TV/VTR selector

Selects the unit to be controlled; tuner, TV or VTR.

17 VTR selector

Selects the command mode.
If your VTR has a command mode selector, set this selector to the same position as that set on the VTR.
If your VTR does not have one, set to 1.
If a Sony 8mm VTR is connected, set to 2.

18 VTR operation buttons

●: Recording
■: Pause
■: Stop
◀: Rewind
▶: Play
▶▶: Fast forward
CH + : For higher numbered channels
CH - : For lower numbered channels
TV/VIDEO: Selects the input signal of the VTR: TV or video.

19 TUNER FM-AM/TV/VTR channel buttons

10-key preset channel buttons: Memorize or recall the preset channels for the unit determined by the setting of the FM-AM/TV/VTR selector.
ENTER : Completes the operation for memory presetting of radio, TV or VTR channels.

20 TV buttons

MTS(Multichannel TV Sound): Receives a multichannel TV sound program when the FM-AM/TV/VTR selector is set to TV.
TV/VTR :Selects the TV signal input.
CH + : Selects a higher TV channel.
CH - : Selects lower TV channel.
VOL + : Increases the sound level.
VOL - : Decreases the sound level.
DISPLAY: Displays the selected signal source on the TV screen.


21 VDP (Video disc player) buttons

◀◀/▶▶: Chapter search
▶: Play
■: Pause
◀◀: Reverse play
▶▶: Fast play
STEREO: Outputs left and right channel sound simultaneously.
Use for bilingual programs.
TV/VDP: Selects TV signal input or disc program.

22 FREE buttons

A - G : Accept learning function when the LEARN/USER/SONY selector is set to LEARN.
Recall the memorized function.

Remote commander RM-177/177D



Installing batteries

Open the battery lid located on the rear.
Insert two (four for RM-E7) size AA (R6) batteries with correct polarity.

Battery life

About a half year of normal operation can be expected when using the Sony SUM-3(NS) batteries.
When the batteries are exhausted, the remote commander cannot operate the unit. If this happens, replace both batteries with new ones.

To avoid battery leakage

When the commander is not to be used for a long time, remove the batteries to avoid damage caused by battery leakage and corrosion.


To avoid malfunction of the commander

Keep the commander away from extremely hot or humid place.

Coverage of the remote commander

The commander can remotely control the equipments placed within the distance of 7m.

How to use learning function (RM-E7 only)



1 Set LEARN/USER/SONY to LEARN.

The READY indicator lights up.

2 Turn this commander towards another commander and press one of the FREE buttons.

If the selected button is inoperative, the READY indicator flickers.

3 While keeping the FREE button pressed, press the desired function button on the other commander.

The function is memorized by this unit. When the memorization is completed, the READY indicator goes out and the LEARNED indicator lights up.

4 Release the FREE button.

The LEARNED indicator goes out and the READY indicator lights up to indicate that the next learning is ready to start.

When learning is finished

Set the LEARN/USER/SONY selector to a position other than LEARN. The READY indicator goes out.

To use the learned function

Set the LEARN/USER/SONY selector to USER.

To use for other functions than learning

Set the LEARN/USER/SONY selector to SONY.

Note

The memorization will be remained for two or three days without installing the batteries.

Index sheet

Use the supplied index sheet by placing it on the FREE buttons for further reference.

CAUTION

Be sure to confirm if the functions have been stored as a few of the functions of other manufacturer commanders are not storable on this commander.


**NOTE ON REPAIRING
DISASSEMBLY AND ASSEMBLY FOR SWITCH SECTION**

Note: Follow the assembly procedure in the numerical order given.


DISASSEMBLY

Insert in the screwdriver and remove the wiring as illustrated below

CAUTION: Don't pull the wiring. It causes the wiring damage.



ASSEMBLY



SECTION 1 ADJUSTMENTS

TA-E77ESD Only

- The adjustments are required CD player having digital output followed to the DAI format (ex. CDP-552ESD or CDP-650ESD)


FS (Sampling frequency) Lamp Adjustment

This set automatically perceives the sampling frequency of digital signal applied. The sampling frequency, 44kHz or 48kHz, is checked by comparator (IC711) that compares the voltage applied to VCO of D FIL PLL with the reference voltage.


The FS lamp adjustment is made to adjust this reference voltage.

Note: Wait for about 10 minutes when TH701 and C735 that are employed for thermal compensation are warmed by soldering iron.


Procedure:



Adjustment Location: DAS board



• CIRCUIT BOARDS LOCATION



• SEMICONDUCTOR LEAD LAYOUTS

M5F7805 M5F78M12 NJM78M05FA NJM7812FA	M54562P (Top view)	2SA1048-GR 2SA1345 2SA1348 2SC634SP 2SC3402	2SK147 cathode anode	30DF2 cathode anode
CX23065 1 2 3 4 5 6 7 8	NJM79M05FA NJM79M12FA 1 2 3 4 5 6 7 8 9 10 11 12 13	M4066BP MC74HC74N SN74LS624N TC4093BP TC74HC00P TC74HC04P TC74HC86P TC74HC393P 1 2 3 4 5 6 7 8 9 10 11 12 13 14	2SA1138 2SC2676 E C B	2SK244 D1 G1 S1 D2 S2 NC Marking
CXD1076P 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28	μPD75104WC-078 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33	M5209P M5220P NJM5532D-D TL072ACP 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28	2SB548-R 2SC2682 letter side	SEL2210S-D S G D anode cathode
CXD1088Q 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34	2SA985-P 2SA1383 2SC2275A 2SC3514 1 2 3 4 5 6 7 8	1SS132 10E2N HZ6A2L HZ6C2L HZ18-3 HZ22-2L	2SC945-P E C B	SEL2213C cathode anode
LA7220 M54566P MC14028BF MC74HC112N PCM56P-JS TC74HC123P 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16	M54543L 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16			SEL2510C short cathode anode

**SECTION 2
DIAGRAMS**

2-1. MOUNTING DIAGRAM (1)

— Conductor side —


- See page 14 for circuit boards location.
- See page 14 for semiconductor lead layouts.

• SEMICONDUCTOR LOCATION

Ref. No.	Location	Ref. No.	Location
IC406	G-7	IC801	H-6
IC407	D-9	IC802	F-6
IC453	G-6	IC803	E-6
IC454	D-9	IC851	H-7
IC701	A-6	IC852	F-7
IC702	A-7	IC853	E-7
IC703	B-8	Q701	B-10
IC704	B-8	Q702	D-8
IC705	B-9	Q703	D-8
IC706	B-10	Q704	D-11
IC707	B-10	Q705	E-11
IC708	C-11	D701	B-8
IC709	C-11	D702	A-8
IC710	D-11	D703	E-7
IC711	C-8	D704	C-7
IC712	F-11	D705	E-11
IC713	G-11	D706	B-9
IC714	H-11		
IC715	H-10		
IC716	E-8		
IC717	F-8		
IC718	E-10		
IC719	F-9		
IC720	H-8		
IC721	G-8		


**— D/A CONVERTER SECTION —
(TA-E77ESD ONLY)**

**— D/A CONVERTER SECTION —
(TA-E77ESD ONLY)**



Note on Mounting Diagram (1):

- Color code of sleeving over the end of the jacket.




- — : part extracted from the component side.
- - - : part extracted from the conductor side.
- ■ : part mounted on the conductor side.

2-2. SCHEMATIC DIAGRAM (1)


— D/A CONVERTER SECTION —
(TA-E77ESD ONLY)

— D/A CONVERTER SECTION —
(TA-E77ESD ONLY)




**— D/A CONVERTER SECTION —
(TA-E77ESD ONLY)**

**— D/A CONVERTER SECTION —
(TA-E77ESD ONLY)**



- D/A CONVERTER SECTION -
(TA-E77ESD ONLY)



Note on Schematic Diagram (1):

- All capacitors are in μ F unless otherwise noted. pF: $\mu\mu$ F 50 WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in Ω and $1/4$ W or less unless otherwise specified.
- : signal path.

Note: The components identified by shading and mark are critical for safety. Replace only with part number specified.

Note: Les composants identifiés par une trame et une marque sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

- : B+ bus.
- : B- bus.
- : adjustment for repair.
- Voltages are dc with respect to ground unless otherwise noted.
- Readings are taken under no-signal conditions with a VOM (50 k Ω /V). No mark: DIGITAL 1 () : DIGITAL 2 () : DAT
- Voltage variations may be noted due to normal production tolerances.
- Waveforms are taken to ground in no-signal conditions by using oscilloscope. Voltage variations may be noted due to normal production tolerances.

A
B
C
D
E
F
G
H
I
J

- Conductor side —
- CONTROL AMP SECTION —

● SEMICONDUCTOR LOCATION


Ref. No.	Location	Ref. No.	Location	Ref. No.	Location
IC101	I-7	Q253	H-3	D609	E-27
IC201	G-2	Q254	H-3	D610	E-21
IC401	I-9	Q255	H-3	D611	G-30
IC402	H-10	Q401	J-10	D612	J-17
IC404	K-31	Q402	I-10	D613	J-17
IC405	K-30	Q451	I-7	D614	I-17
IC451	H-10	Q452	I-8	D615	I-17
IC501	B-19	Q501	A-19	D616	J-19
IC502	B-20	Q502	B-20	D617	J-19
IC601	C-28	Q503	B-20	D618	I-19
IC602	C-26	Q504	B-18	D619	I-19
IC603	F-26	Q601	C-26	D620	J-18
IC604	H-27	Q603	C-25	D621	J-18
IC605	I-27	Q604	B-25	D622	I-19
IC606	H-26	Q691	C-25	D623	I-19
IC607	D-12	Q692	B-25	D624	I-18
IC608	D-12	Q951	A-16	D625	I-18
IC609	E-13	Q952	A-16	D626	I-18
IC610	F-22	Q953	A-16	D627	I-18
IC611	I-24	Q954	A-17	D628	I-12
IC951	B-13	Q955	A-17	D629	I-12
IC952	B-16	Q956	A-17	D630	J-12
IC953	B-17			D631	J-12
				D632	I-12
				D633	I-12
Q101	F-8	D101	F-7	D634	I-22
Q103	E-8	D102	H-5	D635	I-22
Q104	F-9	D103	I-5	D636	J-22
Q105	F-9	D151	F-10	D637	J-22
Q106	G-9	D401	H-30	D638	I-22
Q107	F-7	D402	H-30	D639	I-22
Q108	G-7	D403	I-9	D640	I-17
Q109	G-9	D404	I-10	D641	I-17
Q110	G-7	D405	K-29	D642	I-20
Q151	F-10	D406	J-31	D643	I-20
Q153	E-10	D451	I-30	D644	I-20
Q154	F-9	D452	I-30	D645	D-20
Q155	F-9	D453	I-8	D650	B-27
Q156	G-9	D454	I-8	D651	C-27
Q157	F-11	D501	A-18	D652	F-27
				D691	C-26
Q158	G-11	D502	A-18		
Q159	G-9	D503	A-18		
Q160	G-10	D504	A-18		
Q201	F-1	D601	B-27		
Q202	F-1	D602	B-27		
Q203	H-1	D603	B-27		
Q204	H-1	D604	B-26		
Q205	H-1	D605	C-26		
Q251	F-2	D607	C-21		
Q252	F-3	D608	E-27		

Note on Mounting Diagram (2):

- Color code of sleeving over the end of the jacket.
- ○ : parts extracted from the component side.
- ● : parts extracted from the conductor side.
- ■ : part mounted on the conductor side.


- See page 14 for semiconductor lead layouts.
- See page 21 for notes and semiconductor location.

— CONTROL AMP SECTION —




- CONTROL AMP SECTION -


- CONTROL AMP SECTION -



– CONTROL AMP SECTION –




- CONTROL AMP SECTION -



2-4. SCHEMATIC DIAGRAM (2)

— CONTROL AMP SECTION —


— CONTROL AMP SECTION —




– CONTROL AMP SECTION –

– CONTROL AMP SECTION –

11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26



- CONTROL AMP SECTION -



- CONTROL AMP SECTION -

Note on Schematic Diagram (2):

- All capacitors are in μF unless otherwise noted. pF : μF 50 WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in Ω and $1/4\text{W}$ or less unless otherwise specified.
- : signal path (DIGITAL).

Note: The components identified by shading and mark are critical for safety. Replace only with part number specified.

Note: Les composants identifiés par une trame et une marque sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

- Components for right channel have same values as for left channel. Reference numbers are coded from 150, 250, 350.
- % : indicates tolerance.
- : nonflammable resistor.
- Switch

Ref. No.	Switch	Position
S101	AUDIO REC SELECTOR	PHONO
S102	AUDIO REC SELECTOR	INPUT SOURCE
S103	OUTPUT	ON
S201	CARTRIDGE	MM
S301	SUBSONIC, MODE	400Hz
S302	TURNOVER (BASS)	3kHz
S303	TURNOVER (TREBLE)	OFF
S601	DIGITAL-1	OFF
S602	DIGITAL-2	OFF
S603	PHONO	OFF
S604	TUNER	OFF
S605	CD	OFF
S606	AUX	OFF
S607	TAPE-1	OFF
S608	TAPE-2	OFF
S609	VIDEO-3	OFF
S610	VIDEO-1	OFF
S611	VIDEO-2	OFF
S612	ADAPTOR	OFF
S613	DAT	OFF
S614	SOURCE DIRECT	OFF
S615	MUTING -20dB	OFF
S616	POWER	OFF
S951	VOLTAGE SELECTOR	220V-240V

- : B+ bus.
- : B- bus.
- Voltages are dc with respect to ground unless otherwise noted.
- Readings are taken under no-signal conditions with a VOM (50 k Ω /V).
No mark: PHONO
- V1: VIDEO 1
V2: VIDEO 2
V3: VIDEO 3
- Voltage variations may be noted due to normal production tolerances.
- Waveforms are taken to ground in no-signal conditions by using oscilloscope.
Voltage variations may be noted due to normal production tolerances.

SECTION 3
EXPLODED VIEWS AND PARTS LIST

NOTE:

• The mechanical parts with no reference number in the exploded views are not supplied.


• Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

• The construction parts of an assembled part are indicated with a collation number in the remark column.


• Color Indication of Appearance Parts
Example: (RED) KNOB, BALANCE
(WHITE) Cabinet's Color Parts' Color

The components identified by shading and mark  are critical for safety. Replace only with part number specified.
Les composants identifiés par une trame et une marque  sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

(1)



(2)




(3)

1


No.	Part No.	Description	Remarks	No.	Part No.	Description	Remarks
1	X-4922-208-1	(E77ESD)...PANEL ASSY, FRONT		11	X-4922-201-1	KNOB ASSY	
	X-4922-209-1	(E77ES)...PANEL ASSY, FRONT		12	*4-901-919-00	HOUSE, LED LAMP	
2	*X-4922-203-1	(E77ESD)...HOLDER ASSY, LENS		13	4-916-746-01	KNOB (DIA.21)	
3	X-4922-202-1	HOUSING (A) ASSY		14	4-916-745-01	KNOB (DIA.21)	
4	X-4922-204-0	(E77ES)...HOUSING (C) ASSY		15	4-855-804-11	KNOB, SQUARE	
	X-4922-205-1	(E77ESD)...HOUSING (B) ASSY		16	*4-864-307-00	RING	
5	X-4922-206-2	PLATE (LEFT) ASSY, SIDE, ORNAMENTAL		17	4-908-046-01	KNOB, SQUARE	
6	4-885-979-11	SCREW (4X25)		18	7-682-548-09	SCREW +B 3X8	
7	4-922-238-01	PLATE, TOP		19	7-682-547-09	SCREW +BVTT 3X6 (S)	
8	4-921-439-01	SCREW (M3X8), FLAT HEAD		20	7-685-133-19	SCREW +BTP 2.6X6 TYPE 2 N-S	
9	X-4922-207-2	PLATE (RIGHT) ASSY, SIDE, ORNAMENTAL		901	*1-623-841-11	PC BOARD, FUNCTION	
10	3-533-938-00	CLOTH		902	*1-623-843-11	PC BOARD, REMOCON RECEIVE	
				903	*1-623-844-11	PC BOARD, LED	

No.	Part No.	Description	Remarks	No.	Part No.	Description	Remarks
51	*4-922-237-01	CHASSIS, FRONT		906	*1-623-833-11	PC BOARD, TONE	
52	*4-922-210-02	CASE (C), SHIELD		907	*1-623-842-11	PC BOARD, POWER SW	
53	*4-922-231-01	BRACKET, MICRO COMPUTER PCBOARD		908	*1-623-839-11	PC BOARD, HEADPHONE	
54	*4-922-230-01	BRACKET, EQ PC BOARD		909	*1-623-834-11	PC BOARD, PIN JACK	
55	7-682-547-09	SCREW +BVTT 3X6 (S)		910	*A-4375-333-A	(E77ESD)...MOUNTED PCB, MICRO COMPUTER	
56	7-685-647-79	SCREW +BVTP 3X10 TYPE2			*A-4375-334-A	(E77ES)...MOUNTED PCB, MICRO COMPUTER	
57	7-685-647-79	(E77ESD)...SCREW +BVTT 3X10 TYPE2		912	*1-535-492-00	PIN, GT	
	7-685-871-09	(E77ES)...SCREW +BVTT 3X6 (S)		915	*1-623-831-11	PC BOARD, EQ	
58	7-685-873-09	SCREW +BVTT 3X10 (S)		916	*1-560-242-21	BUS BAR 4P	
904	1-571-246-11	SWITCH, ROTARY		919	*1-623-837-11	PC BOARD, MOTOR	
905	1-571-245-11	(E77ESD)...SWITCH, ROTARY (REMOTE)		920	*1-623-836-11	PC BOARD, MASTER VR	
	1-571-247-11	(E77ES)...SWITCH, ROTARY (REMOTE)		921	*1-623-832-11	PC BOARD, BALANCE	
				922	1-571-244-11	SWITCH, ROTARY (REMOTE)	
101	*4-901			110	*4-92		
102	7-68			111	3-65		
103	4-92			112	*4-92		
104	4-90			113	*4-91		
105	*4-90			114	*4-92		
115	7-68			116	7-68		
116	7-68			117	7-68		
117	7-68			118	7-68		



The components identified by shading and mark A are critical for safety. Replace only with part number specified.	Les composants identifiés par une trame et une marque A sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.
---	---

No.	Part No.	Description	Remarks	No.	Part No.	Description	Remarks
101	*4-908-892-01	SPACER		119	*4-922-203-01	(UK).....LABEL , MODEL NUMBER	
102	7-683-325-07	BOLT, HEXAGON 4X20			*4-922-204-01	(E77ES).....LABEL , MODEL NUMBER(E2/3)	
103	4-922-236-01	BRACKET, TRANSFORMER			*4-922-205-01	(US,Canadian)....LABEL , MODEL NUMBER(U/CA)	
104	4-908-881-01	NUT (M4), FLANGE			*4-922-206-01	(AEP).....LABEL , MODEL NUMBER(AE1)	
105	*4-908-885-01	LABEL, TRANSFORMER			*4-922-206-11	(AEP).....LABEL , MODEL NUMBER(AE2)	
					*4-922-208-02	(G-AEP).....LABEL , MODEL NUMBER	
106	*4-921-402-01	HEAT SINK		120	3-550-458-01	(E77ES)....LABEL , CAUTION , POWER SELECTOR	
107	*3-683-631-01	CLAMP		911	*A-4358-192-A	(US,Canadian,AEP,UK)....MOUNTED PCB , MAIN	
108	*4-922-246-01	REINFORCEMENT			*A-4358-193-A	(E).....MOUNTED PCB , MAIN	
109	*4-908-950-01	REINFORCEMENT (A) , PWB			*A-4358-196-A	(G-AEP)....MOUNTED PCB , MAIN	
110	*4-921-410-11	(E77ESD)....CUSHION		912	*1-535-492-00	PIN, GT	
	*4-921-410-41	(E77ES)....CUSHION		913	*1-623-835-11	PC BOARD , MAIN SUPPORT	
111	3-655-653-21	BAND (TAITON) , BINDING		914	*1-560-242-41	BUS BAR 11P	
112	*4-922-211-01	(E77ESD)....SPACER, PC BOARD		917	*1-623-846-11	(E77ESD)....PC BOARD , D-IN	
113	*4-913-152-01	ESCUTCHEON, D/O		918	*1-623-847-11	(E77ESD)....PC BOARD , D-OUT	
114	*4-922-213-01	CASE (B) , SHIELD		Q402	8-729-107-53	TRANSISTOR 2SC2275A	
115	7-685-760-09	SCREW +BVTT 4X6 (S)		Q452	8-729-118-53	TRANSISTOR 2SA985-P	
116	7-685-647-79	SCREW +BVTP 3X10 TYPE2		T952	A-1-449-014-11	TRANSFORMER, POWER	
117	7-682-548-09	SCREW +B .3X8					
118	7-682-547-09	SCREW +BVTT 3X6 (S)					



The components identified by shading and mark A are critical for safety. Replace only with part number specified.

Les composants identifiés par une trame et une marque A sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

No.	Part No.	Description	Remarks	No.	Part No.	Description	Remarks
51	X-4922-210-1	CHASSIS ASSY, MAIN		923	1-535-416-00	TERMINAL	
52	*4-921-410-31	CUSHION		924	A1-559-271-11	(AEP,G-AEP)...CORD, POWER	
53	*3-309-144-01	HEAT SINK		A1-559-272-11	(UK).....CORD, POWER		
54	4-916-783-01	BUSHING, CORD		A1-559-297-11	(E).....CORD, POWER		
55	*4-922-240-01	(AEP,G-AEP)...PANEL, BACK		A1-559-479-11	(US,Canadian)...CORD, POWER		
	*4-922-241-01	(UK).....PANEL, BACK		925	*	PC BOARD, SIRCS	
	*4-922-242-01	(E).....PANEL, BACK		926	*A-4375-336-A	(E77ESD)...MOUNTED PCB, DAS	
	*4-922-239-01	(US,Canadian)...PANEL, BACK		927	*1-560-242-51	(E77ESD)...BUS BAR 7P	
56	X-4854-207-0	TERMINAL ASSY, GROUND		928	*1-560-242-11	(E77ESD)...BUS BAR 3P	
57	*4-916-769-01	PLATE, GROUND, 4P		929	*1-560-242-21	BUS BAR 4P	
58	*4-922-233-01	CASE (A), SHIELD		930	A1-526-565-12	(E77ES)...AC PLUG ADAPTOR	
59	*4-921-410-11	(E77ESD)...CUSHION		931	*1-623-838-11	PC BOARD, POWER	
60	*4-922-232-01	(E77ESD)...LID, BOTTOM		933	1-533-183-11	(US,Canadian)...HOLDER, FUSE	
61	*4-922-227-01	(E77ES)...LID, BOTTOM		CNJ951A1-526-751-00	(UK).....OUTLET, AC		
62	7-685-647-79	SCREW +BVTT 3X10 TYPE2 SLIT		CNJ951A1-526-883-00	(US,Canadian,E)...OUTLET, AC		
63	7-685-649-79	SCREW +BVTT 3X14 TYPE2 SLIT		CNJ951A1-526-988-11	(AEP,G-AEP).....OUTLET, AC (CEE)		
64	7-682-547-09	SCREW +BVTT 3X6 (S)		F951 A1-532-740-11	(US,Canadian)...FUSE, GLASS TUBE (1A)		
65	7-682-547-09	(AEP,G-AEP)...SCREW +B 3X6		IC404 A8-759-701-79	IC NJM7812FA		
66	7-685-134-19	(AEP,UK,E)...SCREW +BTP 2.6X8 TYPE2 N-S		S951 A1-570-046-21	(AEP,UK,E)...SWITCH, VOLTAGE CHANGE (VOLTAGE SELECTOR)		
67	7-685-133-19	SCREW +P 2.6X6 TYPE2 NON-SLIT					
68	7-685-876-09	SCREW +BVTT 3X16 (S)					

SECTION 4

ELECTRICAL PARTS LIST

NOTE :

- Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- If there are two or more same circuits in a set such as a stereophonic machine, only typical circuit parts may be indicated and capacitors and resistors in other same circuits may be omitted.

CAPACITORS:
MF: μ F, PF: $\mu\mu$ F.

RESISTORS

- All resistors are in ohms.
- F : nonflammable

COILS

- MMH : mH, UH : μ H

SEMICONDUCTORS

In each case, U : μ , for example:
UA...: μ A..., UPA...: μ PA..., UPC...: μ PC,
UPD...: μ PD...

The components identified by shading and mark \triangle are critical for safety.
Replace only with part number specified.

Les composants identifiés par une trame et une marque \triangle sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

ELECTRICAL PARTS

Ref.No.	Part No.	Description
901	*1-623-841-11	PC BOARD, FUNCTION
902	*1-623-843-11	PC BOARD, REMOCON RECEIVE
903	*1-623-844-11	PC BOARD, LED
904	1-571-246-11	SWITCH, ROTARY
905	1-571-245-11	(E77ESD)...SWITCH, ROTARY (REMOTE)
	1-571-247-11	(E77ES)...SWITCH, ROTARY (REMOTE)
906	*1-623-833-11	PC BOARD, TONE
907	*1-623-842-11	PC BOARD, POWER SW
908	*1-623-839-11	PC BOARD, HEADPHONE
909	*1-623-834-11	PC BOARD, PIN JACK
910	*A-4375-333-A	(E77ESD)...MOUNTED PCB, MICRO COMPUTER
	*A-4375-334-A	(E77ES)...MOUNTED PCB, MICRO COMPUTER
911	*A-4358-192-A	(US,Canadian,AEP,UK)...MOUNTED PCB, MAIN
	*A-4358-193-A	(E)...MOUNTED PCB, MAIN
	*A-4358-196-A	(G-AEP)...MOUNTED PCB, MAIN
912	*1-535-492-00	PIN, GT
913	*1-623-835-11	PC BOARD, MAIN SUPPORT
914	1-560-242-41	BUS BAR 11P
915	*1-623-831-11	PC BOARD, EQ
916	*1-560-242-21	BUS BAR 4P
917	*1-623-846-11	(E77ESD)...PC BOARD, D-IN
918	*1-623-847-11	(E77ESD)...PC BOARD, D-OUT
919	*1-623-837-11	PC BOARD, MOTOR
920	*1-623-836-11	PC BOARD, MASTER VR
921	*1-623-832-11	PC BOARD, BALANCE
922	1-571-244-11	SWITCH, ROTARY (REMOTE)
923	1-535-416-00	TERMINAL
924	A.1-559-271-11	(AEP,G-AEP)...CORD, POWER
	A.1-559-272-11	(UK)...CORD, POWER
	A.1-559-297-11	(E)...CORD, POWER
	A.1-559-479-11	(US,Canadian)...CORD, POWER
925	*	PC BOARD, SIRCS
926	*A-4375-336-A	(E77ESD)...MOUNTED PCB, DAS
927	1-560-242-51	(E77ESD)...BUS BAR 7P
928	*1-560-242-11	(E77ESD)...BUS BAR 3P
929	*1-560-242-21	BUS BAR 4P
930	A.1-526-565-12	(E77ES)...AC PLUG ADAPTOR
931	*1-623-838-11	PC BOARD, POWER
933	1-533-183-11	(US,Canadian)...HOLDER, FUSE
C102	1-124-124-00	ELECT 220MF 20% 10V
C103	1-104-254-11	POLYSTYRENE 560PF 5% 125V
C104	1-107-210-00	MICA 22PF 5% 100V
C105	1-130-673-00	FILM 3.3MF 10% 125V
C106	1-109-621-00	MICA 220PF 5% 100V
C107	1-124-684-71	ELECT 47MF 20% 16V

ELECTRICAL PARTS

Ref.No.	Part No.	Description				
C108	1-123-334-00	ELECT 220MF 20% 25V				
C109	1-123-357-00	ELECT 22MF 20% 50V				
C110	1-107-026-00	MICA 5PF 0.5PF 100V				
C111	1-124-684-71	ELECT 47MF 20% 16V				
C112	1-102-973-00	(G-AEP)...CERAMIC 100PF 5% 50V				
C113	1-102-959-00	(G-AEP)...CERAMIC 22PF 5% 50V				
C114	1-102-977-00	(G-AEP)...CERAMIC 200PF 5% 50V				
C115	1-162-283-31	CERAMIC 120PF 10% 50V				
C152	1-124-124-00	ELECT 220MF 20% 10V				
C153	1-104-254-11	POLYSTYRENE 560PF 5% 125V				
C154	1-107-210-00	MICA 22PF 5% 100V				
C155	1-130-673-00	FILM 3.3MF 10% 125V				
C156	1-109-621-00	MICA 220PF 5% 100V				
C157	1-124-684-71	ELECT 47MF 20% 16V				
C158	1-123-334-00	ELECT 220MF 20% 25V				
C159	1-123-357-00	ELECT 22MF 20% 50V				
C160	1-107-026-00	MICA 5PF 0.5PF 100V				
C161	1-124-684-71	ELECT 47MF 20% 16V				
C162	1-102-973-00	(G-AEP)...CERAMIC 100PF 5% 50V				
C163	1-102-959-00	(G-AEP)...CERAMIC 22PF 5% 50V				
C164	1-102-977-00	(G-AEP)...CERAMIC 200PF 5% 50V				
C165	1-162-283-31	CERAMIC 120PF 10% 50V				
C201	1-104-243-00	(G-AEP)...POLYSTYRENE 56PF 10% 125V				
C201	1-104-249-11	(E)...POLYSTYRENE 330PF 5% 125V				
C202	1-104-150-00	(E)...POLYSTYRENE 680PF 5% 125V				
C202	1-104-151-00	(G-AEP)...POLYSTYRENE 2200PF 5% 125V				
C203	1-123-381-00	ELECT 2.2MF 20% 50V				
C204	1-123-332-00	ELECT 47MF 20% 25V				
C205	1-129-723-00	FILM 0.056MF 2% 630V				
C207	1-130-206-00	FILM 0.016MF 2% 630V				
C208	1-101-361-00	(G-AEP)...CERAMIC 150PF 5% 50V				
C209	1-102-973-00	(G-AEP)...CERAMIC 100PF 5% 50V				
C210	1-101-880-00	(G-AEP)...CERAMIC 47PF 5% 50V				
C251	1-104-243-00	(G-AEP)...POLYSTYRENE 56PF 10% 125V				
C251	1-104-249-11	(E)...POLYSTYRENE 330PF 5% 125V				
C252	1-104-150-00	(E)...POLYSTYRENE 680PF 5% 125V				
C252	1-104-151-00	(G-AEP)...POLYSTYRENE 2200PF 5% 125V				
C253	1-123-381-00	ELECT 2.2MF 20% 50V				
C254	1-123-332-00	ELECT 47MF 20% 25V				
C255	1-129-723-00	FILM 0.056MF 2% 630V				
C257	1-130-206-00	FILM 0.016MF 2% 630V				
C258	1-101-361-00	(G-AEP)...CERAMIC 150PF 5% 50V				
C259	1-102-973-00	(G-AEP)...CERAMIC 100PF 5% 50V				
C260	1-101-880-00	(G-AEP)...CERAMIC 47PF 5% 50V				
C291	1-124-622-11	ELECT 1000MF 20% 50V				
C292	1-124-622-11	ELECT 1000MF 20% 50V				

ELECTRICAL PARTS

Ref.No.	Part No.	Description	Value	Tolerance	Unit
C301	1-136-171-00	FILM	0.33MF	5%	50V
C302	1-136-164-00	FILM	0.082MF	5%	50V
C303	1-136-161-00	FILM	0.047MF	5%	50V
C304	1-130-482-00	MYLAR	0.0082MF	5%	50V
C305	1-130-481-00	MYLAR	0.0068MF	5%	50V
C306	1-130-469-00	MYLAR	680PF	5%	50V
C307	1-130-468-00	MYLAR	560PF	5%	50V
C308	1-130-475-00	MYLAR	0.0022MF	5%	50V
C309	1-130-476-00	MYLAR	0.0027MF	5%	50V
C315	1-136-171-00	FILM	0.33MF	5%	50V
C352	1-136-164-00	FILM	0.082MF	5%	50V
C353	1-136-161-00	FILM	0.047MF	5%	50V
C354	1-130-482-00	MYLAR	0.0082MF	5%	50V
C355	1-130-481-00	MYLAR	0.0068MF	5%	50V
C356	1-130-469-00	MYLAR	680PF	5%	50V
C357	1-130-468-00	MYLAR	560PF	5%	50V
C358	1-130-475-00	MYLAR	0.0022MF	5%	50V
C359	1-130-476-00	MYLAR	0.0027MF	5%	50V
C401	▲ 1-125-431-11	ELECT(BLOCK)	4700MF	20%	63V
C402	1-124-622-11	ELECT	1000MF	20%	50V
C403	1-123-356-00	ELECT	10MF	20%	50V
C404	1-124-725-00	ELECT	100MF	20%	50V
C405	1-123-378-00	ELECT	1000MF	20%	63V
C408	1-123-334-00	(E77ESD)...ELECT	220MF	20%	25V
C410	1-123-332-00	(E77ESD)...ELECT	47MF	20%	25V
C411	▲ 1-124-887-00	(E77ESD)...ELECT	3300MF	20%	16V
C412	▲ 1-124-887-00	(E77ESD)...ELECT	3300MF	20%	16V
C416	▲ 1-124-563-11	ELECT	220MF	20%	25V
C417	1-123-321-00	ELECT	220MF	20%	16V
C418	1-123-333-00	ELECT	100MF	20%	16V
C419	1-136-169-00	FILM	0.22MF	5%	50V
C420	1-136-169-00	(E77ESD)...FILM	0.22MF	5%	50V
C421	1-136-169-00	(E77ESD)...FILM	0.22MF	5%	50V
C451	▲ 1-125-431-11	ELECT(BLOCK)	4700MF	20%	63V
C452	1-124-622-11	ELECT	1000MF	20%	50V
C453	1-123-356-00	ELECT	10MF	20%	50V
C454	1-124-725-00	ELECT	100MF	20%	50V
C455	1-123-378-00	ELECT	1000MF	20%	63V
C458	1-123-334-00	(E77ESD)...ELECT	220MF	20%	25V
C460	1-123-332-00	(E77ESD)...ELECT	47MF	20%	25V
C461	▲ 1-123-324-00	(E77ESD)...ELECT	1000MF	20%	16V
C491	1-130-673-00	FILM	3.3MF	10%	125V
C492	1-136-165-00	FILM	0.1MF	5%	50V
C501	1-123-332-00	(E77ES)...ELECT	47MF	20%	16V
C501	1-124-477-11	(E77ESD)...ELECT	47MF	20%	16V
C502	1-123-332-00	(E77ES)...ELECT	47MF	20%	16V
C502	1-124-477-11	(E77ESD)...ELECT	47MF	20%	16V
C503	1-124-473-11	(E77ESD)...ELECT	1000MF	20%	10V
C503	1-124-559-51	(E77ES)...ELECT	1000MF	20%	10V
C504	1-123-332-00	(E77ES)...ELECT	47MF	20%	16V
C504	1-124-477-11	(E77ESD)...ELECT	47MF	20%	16V
C505	1-124-473-11	(E77ESD)...ELECT	1000MF	20%	10V
C505	1-124-559-51	(E77ES)...ELECT	1000MF	20%	10V
C506	1-124-473-11	(E77ESD)...ELECT	1000MF	20%	10V
C506	1-124-559-51	(E77ES)...ELECT	1000MF	20%	10V
C507	1-123-875-11	ELECT	10MF	20%	50V

ELECTRICAL PARTS

Ref.No.	Part No.	Description	Value	Tolerance	Unit
C508	1-123-332-00	(E77ES)...ELECT	47MF	20%	16V
C508	1-124-477-11	(E77ESD)...ELECT	47MF	20%	16V
C509	1-123-332-00	(E77ES)...ELECT	47MF	20%	16V
C509	1-124-477-11	(E77ESD)...ELECT	47MF	20%	16V
C510	1-123-332-00	(E77ES)...ELECT	47MF	20%	16V
C510	1-124-477-11	(E77ESD)...ELECT	47MF	20%	16V
C511	1-123-332-00	(E77ES)...ELECT	47MF	20%	16V
C511	1-124-477-11	(E77ESD)...ELECT	47MF	20%	16V
C601	▲ 1-123-338-00	ELECT	2200MF	20%	25V
C602	1-136-153-00	FILM	0.01MF	5%	50V
C603	1-123-321-00	ELECT	220MF	20%	16V
C604	1-123-369-00	ELECT	4.7MF	20%	25V
C605	1-124-124-00	ELECT	220MF	20%	6.3V
C606	1-124-958-11	ELECT	39000MF		5.5V
C607	1-123-333-00	ELECT	100MF	20%	16V
C608	1-123-333-00	ELECT	100MF	20%	16V
C609	1-136-153-00	FILM	0.01MF	5%	50V
C610	1-123-323-00	ELECT	470MF	20%	16V
C611	1-123-332-00	ELECT	47MF	20%	16V
C612	1-162-207-31	CERAMIC	22PF	5%	50V
C613	1-162-207-31	CERAMIC	22PF	5%	50V
C614	1-161-379-00	(E77ESD)...CERAMIC	0.01MF	30%	16V
C615	1-161-379-00	(E77ESD)...CERAMIC	0.01MF	30%	16V
C616	1-161-379-00	(E77ESD)...CERAMIC	0.01MF	30%	16V
C617	1-161-379-00	(E77ESD)...CERAMIC	0.01MF	30%	16V
C618	1-161-379-00	(E77ESD)...CERAMIC	0.01MF	30%	16V
C619	1-161-379-00	(E77ESD)...CERAMIC	0.01MF	30%	16V
C620	1-124-123-00	ELECT	100MF	20%	6.3V
C621	1-124-123-00	ELECT	100MF	20%	6.3V
C622	1-123-369-00	ELECT	4.7MF	20%	50V
C623	1-136-165-00	FILM	0.1MF	5%	50V
C624	1-136-165-00	FILM	0.1MF	5%	50V
C625	1-136-165-00	FILM	0.1MF	5%	50V
C626	1-136-169-00	FILM	0.22MF	5%	50V
C701	1-136-153-00	(E77ESD)...FILM	0.01MF	5%	50V
C702	1-123-382-00	(E77ESD)...ELECT	33MF	20%	50V
C703	1-136-153-00	(E77ESD)...FILM	0.01MF	5%	50V
C704	1-123-382-00	(E77ESD)...ELECT	33MF	20%	50V
C705	1-136-153-00	(E77ESD)...FILM	0.01MF	5%	50V
C706	1-123-382-00	(E77ESD)...ELECT	33MF	20%	50V
C707	1-136-153-00	(E77ESD)...FILM	0.01MF	5%	50V
C708	1-124-963-11	(E77ESD)...ELECT	33MF	20%	16V
C709	1-136-153-00	(E77ESD)...FILM	0.01MF	5%	50V
C710	1-136-153-00	(E77ESD)...FILM	0.01MF	5%	50V
C711	1-162-213-31	(E77ESD)...CERAMIC	39PF	5%	50V
C712	1-107-294-00	(E77ESD)...MICA	56PF	5%	100V
C713	1-136-153-00	(E77ESD)...FILM	0.01MF	5%	50V
C714	1-104-150-00	(E77ESD)...POLYSTYRENE	680PF	5%	125V
C715	1-136-153-00	(E77ESD)...FILM	0.01MF	5%	50V
C716	1-136-153-00	(E77ESD)...FILM	0.01MF	5%	50V
C717	1-136-173-00	(E77ESD)...FILM	0.47MF	5%	50V
C718	1-136-153-00	(E77ESD)...FILM	0.01MF	5%	50V
C719	1-124-123-00	(E77ESD)...ELECT	100MF	20%	10V
C720	1-107-165-00	(E77ESD)...MICA	56PF	5%	100V
C721	1-136-153-00	(E77ESD)...FILM	0.01MF	5%	50V
C722	1-136-153-00	(E77ESD)...FILM	0.01MF	5%	50V

The components identified by shading and mark **A** are critical for safety. Replace only with part number specified.

Les composants identifiés par une trame et une marque **A** sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

ELECTRICAL PARTS

Ref.No. Part No. Description

C723	1-123-380-00	(E77ESD)...ELECT	1MF	20%	50V	C806	1-130-848-00	(E77ESD)...FILM	0.0082MF	5%	100V
C724	1-136-153-00	(E77ESD)...FILM	0.01MF	5%	50V	C807	1-130-279-00	(E77ESD)...FILM	0.0018MF	5%	100V
C725	1-130-471-00	(E77ESD)...MYLAR	0.001MF	5%	50V	C808	1-130-729-00	(E77ESD)...FILM	0.0027MF	5%	100V
C726	1-123-330-00	(E77ESD)...ELECT	22MF	20%	25V	C809	1-130-729-00	(E77ESD)...FILM	0.0027MF	5%	100V
C727	1-123-330-00	(E77ESD)...ELECT	22MF	20%	25V	C810	1-107-169-00	(E77ESD)...MICA	100PF	5%	100V
C728	1-123-356-00	(E77ESD)...ELECT	10MF	20%	50V	C811	1-130-475-00	(E77ESD)...MYLAR	0.0022MF	5%	50V
C729	1-123-356-00	(E77ESD)...ELECT	10MF	20%	50V	C812	1-123-373-00	(E77ESD)...ELECT	47MF	20%	63V
C730	1-123-330-00	(E77ESD)...ELECT	22MF	20%	25V	C813	1-109-621-00	(E77ESD)...MICA	220PF	5%	100V
C731	1-162-199-31	(E77ESD)...CERAMIC	10PF	5%	50V	C814	1-123-356-00	(E77ESD)...ELECT	10MF	20%	50V
C732	1-136-153-00	(E77ESD)...FILM	0.01MF	5%	50V	C815	1-136-153-00	(E77ESD)...FILM	0.01MF	5%	50V
C733	1-136-153-00	(E77ESD)...FILM	0.01MF	5%	50V	C816	1-123-333-00	(E77ESD)...ELECT	100MF	20%	16V
C734	1-124-123-00	(E77ESD)...ELECT	100MF	20%	10V	C817	1-124-124-00	(E77ESD)...ELECT	220MF	20%	10V
C735	1-107-157-00	(E77ESD)...MICA	27PF	5%	100V	C818	1-123-332-00	(E77ESD)...ELECT	47MF	20%	16V
C736	1-136-153-00	(E77ESD)...FILM	0.01MF	5%	50V	C819	1-123-332-00	(E77ESD)...ELECT	47MF	20%	16V
C737	1-136-153-00	(E77ESD)...FILM	0.01MF	5%	50V	C851	1-123-332-00	(E77ESD)...ELECT	47MF	20%	16V
C738	1-123-356-00	(E77ESD)...ELECT	10MF	20%	50V	C852	1-123-332-00	(E77ESD)...ELECT	47MF	20%	16V
C739	1-136-153-00	(E77ESD)...FILM	0.01MF	5%	50V	C853	1-123-334-00	(E77ESD)...ELECT	220MF	20%	25V
C740	1-123-356-00	(E77ESD)...ELECT	10MF	20%	50V	C854	1-123-334-00	(E77ESD)...ELECT	220MF	20%	25V
C741	1-136-153-00	(E77ESD)...FILM	0.01MF	5%	50V	C855	1-136-233-11	(E77ESD)...FILM	0.0047MF	5%	100V
C742	1-136-153-00	(E77ESD)...FILM	0.01MF	5%	50V	C856	1-130-848-00	(E77ESD)...FILM	0.0082MF	5%	100V
C743	1-123-356-00	(E77ESD)...ELECT	10MF	20%	50V	C857	1-130-279-00	(E77ESD)...FILM	0.0018MF	5%	100V
C744	1-136-153-00	(E77ESD)...FILM	0.01MF	5%	50V	C858	1-130-729-00	(E77ESD)...FILM	0.0027MF	5%	100V
C747	1-123-335-00	(E77ESD)...ELECT	330MF	20%	25V	C859	1-130-729-00	(E77ESD)...FILM	0.0027MF	5%	100V
C748	1-123-335-00	(E77ESD)...ELECT	330MF	20%	25V	C860	1-107-169-00	(E77ESD)...MICA	100PF	5%	100V
C749	1-123-335-00	(E77ESD)...ELECT	330MF	20%	25V	C861	1-130-475-00	(E77ESD)...MYLAR	0.0022MF	5%	50V
C750	1-123-335-00	(E77ESD)...ELECT	330MF	20%	25V	C862	1-123-373-00	(E77ESD)...ELECT	47MF	20%	63V
C751	1-123-369-00	(E77ESD)...ELECT	4.7MF	20%	50V	C863	1-109-621-00	(E77ESD)...MICA	220PF	5%	100V
C759	1-136-153-00	(E77ESD)...FILM	0.01MF	5%	50V	C864	1-123-356-00	(E77ESD)...ELECT	10MF	20%	50V
C760	1-123-356-00	(E77ESD)...ELECT	10MF	20%	50V	C865	1-136-153-00	(E77ESD)...FILM	0.01MF	5%	50V
C761	1-136-153-00	(E77ESD)...FILM	0.01MF	5%	50V	C866	1-123-333-00	(E77ESD)...ELECT	100MF	20%	16V
C762	1-136-153-00	(E77ESD)...FILM	0.01MF	5%	50V	C867	1-124-124-00	(E77ESD)...ELECT	220MF	20%	10V
C766	1-162-283-31	(E77ESD)...CERAMIC	120PF	10%	50V	C868	1-123-332-00	(E77ESD)...ELECT	47MF	20%	16V
C767	1-124-124-00	(E77ESD)...ELECT	220MF	20%	10V	C869	1-123-332-00	(E77ESD)...ELECT	47MF	20%	16V
C768	1-123-356-00	(E77ESD)...ELECT	10MF	20%	50V	C951	1-124-477-11	(E77ESD)...ELECT	47MF	20%	16V
C769	1-136-153-00	(E77ESD)...FILM	0.01MF	5%	50V	C952	1-124-477-11	(E77ESD)...ELECT	47MF	20%	16V
C770	1-123-356-00	(E77ESD)...ELECT	10MF	20%	50V	C953	1-124-473-11	(E77ESD)...ELECT	1000MF	20%	10V
C771	1-136-153-00	(E77ESD)...FILM	0.01MF	5%	50V	C954	1-124-473-11	(E77ESD)...ELECT	1000MF	20%	10V
C772	1-136-153-00	(E77ESD)...FILM	0.01MF	5%	50V	C955	1-124-477-11	(E77ESD)...ELECT	47MF	20%	16V
C773	1-124-124-00	(E77ESD)...ELECT	220MF	20%	10V	C956	1-124-477-11	(E77ESD)...ELECT	47MF	20%	16V
C774	1-136-153-00	(E77ESD)...FILM	0.01MF	5%	50V	C957	1-124-473-11	(E77ESD)...ELECT	1000MF	20%	10V
C775	1-123-356-00	(E77ESD)...ELECT	10MF	20%	50V	C958	1-124-473-11	(E77ESD)...ELECT	1000MF	20%	10V
C776	1-123-356-00	(E77ESD)...ELECT	10MF	20%	50V	C959	1-123-356-00	(E77ESD)...ELECT	10MF	20%	16V
C777	1-136-169-00	(E77ESD)...FILM	0.22MF	5%	50V	C960	1-123-356-00	(E77ESD)...ELECT	10MF	20%	16V
C778	1-136-169-00	(E77ESD)...FILM	0.22MF	5%	50V	C961	1-124-477-11	(E77ESD)...ELECT	47MF	20%	16V
C779	1-136-169-00	(E77ESD)...FILM	0.22MF	5%	50V	C963	1-124-477-11	(E77ESD)...ELECT	47MF	20%	16V
C781	1-162-282-31	(E77ESD)...CERAMIC	100PF	10%	50V	C991	A-1-161-744-00	CERAMIC	0.01MF		400V
C790	1-126-103-11	(E77ESD)...ELECT	470MF	20%	16V	C992	A-1-130-710-00	(G-AEP)...FILM	0.1MF	20%	250V
C791	1-126-103-11	(E77ESD)...ELECT	470MF	20%	16V	C992	A-1-136-345-21	(US)...FILM	0.1MF	20%	125V
C792	1-162-218-31	(E77ESD)...CERAMIC	62PF	5%	50V	CNJ951A1-526-751-00	(UK)...OUTLET, AC				
C793	1-136-153-00	(E77ESD)...FILM	0.01MF	5%	50V	CNJ951A1-526-883-00	(US,Canadian,E)...OUTLET, AC				
C794	1-162-219-31	(E77ESD)...CERAMIC	68PF	5%	50V	CNJ951A1-526-988-11	(AEP, G-AEP)...OUTLET, AC (EE)				
C795	1-161-377-00	(E77ESD)...CERAMIC	0.0047MF	20%	50V	CN112	*1-562-327-00	(E77ESD)...SOCKET, CONNECTOR 3P			
C796	1-161-379-00	(US, G-AEP)...CERAMIC	0.01MF	30%	16V	CN113	*1-562-327-00	SOCKET, CONNECTOR 3P			
C797	1-161-379-00	(US, G-AEP)...CERAMIC	0.01MF	30%	16V	CN114	*1-562-249-00	SOCKET, CONNECTOR 4P			
C798	1-161-379-00	(US, G-AEP)...CERAMIC	0.01MF	30%	16V	CN115	*1-562-327-00	SOCKET, CONNECTOR 3P			
C801	1-123-332-00	(E77ESD)...ELECT	47MF	20%	16V	CN116	*1-562-327-00	SOCKET, CONNECTOR 3P			
C802	1-123-332-00	(E77ESD)...ELECT	47MF	20%	16V	CN117	*1-562-327-00	(E77ESD)...SOCKET, CONNECTOR 3P			
C803	1-123-334-00	(E77ESD)...ELECT	220MF	20%	25V						
C804	1-123-334-00	(E77ESD)...ELECT	220MF	20%	25V						
C805	1-136-233-11	(E77ESD)...FILM	0.0047MF	5%	100V						

The components identified by shading and mark **A** are critical for safety. Replace only with part number specified.

Les composants identifiés par une trame et une marque **A** sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

ELECTRICAL PARTS

Ref.No.	Part No.	Description
CN161	*1-562-327-00	SOCKET, CONNECTOR 3P
CN203	*1-562-249-00	SOCKET, CONNECTOR 4P
CN301	*1-562-249-00	SOCKET, CONNECTOR 4P
CN302	*1-562-249-00	SOCKET, CONNECTOR 4P
CN303	*1-562-249-00	SOCKET, CONNECTOR 4P
CN304	*1-562-249-00	SOCKET, CONNECTOR 4P
CN305	*1-562-249-00	SOCKET, CONNECTOR 4P
CN306	*1-562-327-00	SOCKET, CONNECTOR 3P
CN403	*1-562-327-00	SOCKET, CONNECTOR 3P
CN404	*1-562-327-00	(E77ESD)...SOCKET, CONNECTOR 3P
CN405	*1-562-327-00	SOCKET, CONNECTOR 3P
CN406	*1-562-327-00	SOCKET, CONNECTOR 3P
CN407	*1-562-327-00	SOCKET, CONNECTOR 3P
CN501	*1-562-327-00	SOCKET, CONNECTOR 3P
CN615	*1-562-327-00	SOCKET, CONNECTOR 3P
CN616	*1-562-327-00	SOCKET, CONNECTOR 3P
CN617	*1-562-327-00	SOCKET, CONNECTOR 3P
CN618	*1-562-327-00	SOCKET, CONNECTOR 3P
CN619	*1-562-327-00	SOCKET, CONNECTOR 3P
CN620	*1-562-327-00	SOCKET, CONNECTOR 3P
CNP101	*1-564-507-11	PLUG, CONNECTOR 4P
CNP103	*1-564-506-11	PLUG, CONNECTOR 3P
CNP104	*1-564-506-11	PLUG, CONNECTOR 3P
CNP105	*1-564-506-11	(E77ESD)...PLUG, CONNECTOR 3P
CNP106	*1-564-505-11	PLUG, CONNECTOR 2P
CNP107	*1-564-505-31	PLUG, CONNECTOR 2P
CNP108	*1-564-506-11	PLUG, CONNECTOR 3P
CNP109	*1-564-506-11	PLUG, CONNECTOR 3P
CNP110	*1-564-506-11	PLUG, CONNECTOR 3P
CNP111	*1-564-506-11	PLUG, CONNECTOR 3P
CNP151	*1-564-507-41	PLUG, CONNECTOR 4P
CNP152	*1-564-507-21	PLUG, CONNECTOR 4P
CNP153	*1-564-507-11	PLUG, CONNECTOR 4P
CNP154	*1-564-507-31	PLUG, CONNECTOR 4P
CNP156	*1-564-505-11	PLUG, CONNECTOR 2P
CNP157	*1-564-507-21	PLUG, CONNECTOR 4P
CNP158	*1-564-505-21	PLUG, CONNECTOR 2P
CNP159	*1-564-505-31	PLUG, CONNECTOR 2P
CNP160	*1-564-505-21	PLUG, CONNECTOR 2P
CNP201	*1-564-506-11	PLUG, CONNECTOR 3P
CNP202	*1-564-506-11	PLUG, CONNECTOR 3P
CNP401	*1-564-506-11	PLUG, CONNECTOR 3P
CNP402	*1-564-505-41	PLUG, CONNECTOR 2P
CNP601	*1-564-509-11	PLUG, CONNECTOR 6P
CNP602	*1-564-506-11	PLUG, CONNECTOR 3P
CNP603	*1-564-508-11	PLUG, CONNECTOR 5P
CNP604	*1-564-505-11	PLUG, CONNECTOR 2P
CNP605	*1-564-505-41	PLUG, CONNECTOR 2P
CNP606	*1-564-505-11	PLUG, CONNECTOR 2P
CNP607	*1-564-342-11	PIN, CONNECTOR 8P
CNP608	*1-564-666-11	PIN, CONNECTOR 10P
CNP609	*1-564-666-11	PIN, CONNECTOR 10P
CNP610	*1-564-505-31	PLUG, CONNECTOR 2P
CNP611	*1-564-506-11	PLUG, CONNECTOR 3P
CNP613	*1-564-505-31	PLUG, CONNECTOR 2P
CNP614	*1-564-505-11	PLUG, CONNECTOR 2P

ELECTRICAL PARTS

Ref.No.	Part No.	Description
CNP691	*1-564-506-11	PLUG, CONNECTOR 3P
CNP701	*1-564-510-11	(E77ESD)...PLUG, CONNECTOR 7P
CNP702	*1-564-505-11	(E77ESD)...PLUG, CONNECTOR 2P
CNP703	*1-564-505-31	(E77ESD)...PLUG, CONNECTOR 2P
CNP704	*1-564-505-21	(E77ESD)...PLUG, CONNECTOR 2P
CNP705	*1-564-505-41	(E77ESD)...PLUG, CONNECTOR 2P
CNP706	*1-564-506-11	(E77ESD)...PLUG, CONNECTOR 3P
CNP707	*1-564-506-11	(E77ESD)...PLUG, CONNECTOR 3P
CNP708	*1-564-506-11	(E77ESD)...PLUG, CONNECTOR 3P
D101	8-719-910-62	DIODE HZ6A2L
D102	8-719-940-76	DIODE 1SS132
D103	8-719-940-76	DIODE 1SS132
D151	8-719-910-62	DIODE HZ6A2L
D401	△ 8-719-230-02	DIODE 30DF2
D402	△ 8-719-230-02	DIODE 30DF2
D403	8-719-902-22	DIODE HZ22-2L
D404	8-719-902-83	DIODE HZ18-3
D405	△ 9-982-270-01	(E77ESD)...DIODE S2VB40
D406	△ 9-982-270-01	DIODE S2VB40
D451	△ 8-719-230-02	DIODE 30DF2
D452	△ 8-719-230-02	DIODE 30DF2
D453	8-719-902-22	DIODE HZ22-2L
D454	8-719-902-83	DIODE HZ18-3
D501	8-719-940-76	DIODE 1SS132
D502	8-719-940-76	DIODE 1SS132
D503	8-719-940-76	DIODE 1SS132
D504	8-719-940-76	DIODE 1SS132
D601	△ 8-719-200-77	DIODE 10E2N
D602	△ 8-719-200-77	DIODE 10E2N
D603	△ 8-719-200-77	DIODE 10E2N
D604	△ 8-719-200-77	DIODE 10E2N
D605	8-719-940-76	DIODE 1SS132
D607	8-719-300-82	DIODE SEL2213C
D608	8-719-940-76	DIODE 1SS132
D609	8-719-940-76	DIODE 1SS132
D610	8-719-200-77	DIODE 10E2N
D611	8-719-940-76	DIODE 1SS132
D612	8-719-301-39	(E77ESD)...DIODE SEL2210S-D
D613	8-719-301-39	(E77ESD)...DIODE SEL2210S-D
D614	8-719-301-39	(E77ESD)...DIODE SEL2210S-D
D615	8-719-301-39	(E77ESD)...DIODE SEL2210S-D
D616	8-719-301-39	DIODE SEL2210S-D
D617	8-719-301-39	DIODE SEL2210S-D
D618	8-719-301-39	DIODE SEL2210S-D
D619	8-719-301-39	DIODE SEL2210S-D
D620	8-719-301-39	DIODE SEL2210S-D
D621	8-719-301-39	DIODE SEL2210S-D
D622	8-719-301-39	DIODE SEL2210S-D
D623	8-719-301-39	DIODE SEL2210S-D
D624	8-719-301-39	DIODE SEL2210S-D
D625	8-719-301-39	DIODE SEL2210S-D
D626	8-719-301-39	DIODE SEL2210S-D
D627	8-719-301-39	DIODE SEL2210S-D
D628	8-719-301-39	DIODE SEL2210S-D
D629	8-719-301-39	DIODE SEL2210S-D
D630	8-719-301-39	DIODE SEL2210S-D
D631	8-719-301-39	DIODE SEL2210S-D

The components identified by shading and mark △ are critical for safety. Replace only with part number specified.

Les composants identifiés par une trame et une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

ELECTRICAL PARTS

Ref.No.	Part No.	Description
D632	8-719-301-39	DIODE SEL2210S-D
D633	8-719-301-39	DIODE SEL2210S-D
D634	8-719-301-39	DIODE SEL2210S-D
D635	8-719-301-39	DIODE SEL2210S-D
D636	8-719-303-00	DIODE SEL2510C
D637	8-719-303-00	DIODE SEL2510C
D638	8-719-301-39	DIODE SEL2210S-D
D639	8-719-301-39	DIODE SEL2210S-D
D640	8-719-301-39	(E77ESD)...DIODE SEL2210S-D
D641	8-719-301-39	(E77ESD)...DIODE SEL2210S-D
D642	8-719-303-00	(E77ESD)...DIODE SEL2510C
D643	8-719-303-00	(E77ESD)...DIODE SEL2510C
D644	8-719-303-00	(E77ESD)...DIODE SEL2510C
D645	8-719-940-76	DIODE 1SS132
D650	8-719-940-76	DIODE 1SS132
D651	8-719-940-76	DIODE 1SS132
D652	8-719-940-76	DIODE 1SS132
D691	8-719-940-76	DIODE 1SS132
D701	8-719-940-76	(E77ESD)...DIODE 1SS132
D702	8-719-940-76	(E77ESD)...DIODE 1SS132
D703	8-719-940-76	(E77ESD)...DIODE 1SS132
D704	8-719-910-68	(E77ESD)...DIODE HZ6C2L
D705	8-719-940-76	(E77ESD)...DIODE 1SS132
D706	8-719-940-76	(E77ESD)...DIODE 1SS132

F951 A1-532-740-11 (US,Canadian)...FUSE, GLASS TUBE (1A)

IC101	8-759-701-21	IC NJM5532D-D
IC201	8-759-602-01	(G-AEP)...IC M5220P
IC201	8-759-701-21	(US,Canadian,AEP,UK,E)...IC NJM5532D-D
IC401	8-759-602-31	IC M5209P
IC402 A1-759-604-39	(E77ESD)...IC M5F78M12	
IC404 A1-759-701-79	IC NJM7812FA	
IC405 A1-759-604-29	IC M5F7805	
IC406 A1-759-701-56	(E77ESD)...IC NJM78M05FA	
IC407 A1-759-701-56	(E77ESD)...IC NJM78M05FA	
IC451 A1-759-701-69	(E77ESD)...IC NJM79M12FA	
IC452 A1-759-701-65	(E77ESD)...IC NJM79M05FA	
IC454 A1-759-701-65	(E77ESD)...IC NJM79M05FA	
IC501	8-759-601-43	IC M4066BP
IC502	8-759-801-61	IC LA7220
IC601 A1-759-701-56	IC NJM78M05FA	
IC602	8-759-240-93	IC TC4093BP
IC603	8-759-113-52	IC UPD75104CW-078
IC604	8-759-601-03	IC M54566P
IC605	8-759-601-03	IC M54566P
IC606	8-759-601-03	IC M54566P
IC607	8-759-008-95	IC MC14028BF
IC608	8-759-600-68	IC M54562P
IC609	8-759-600-68	IC M54562P
IC610 A1-759-600-24	IC M54543L	
IC611	8-741-131-70	IC BX-1317
IC701	8-759-202-11	(E77ESD)...IC TC74HC00P
IC702	8-759-202-11	(E77ESD)...IC TC74HC00P
IC703	8-759-202-74	(E77ESD)...IC TC74HC04P
IC704	8-759-001-26	(E77ESD)...IC MC74HC112N
IC705	8-759-202-24	(E77ESD)...IC TC74HC86P

ELECTRICAL PARTS

Ref.No.	Part No.	Description
IC706	8-759-202-86	(E77ESD)...IC TC74HC123P
IC707	8-759-918-71	(E77ESD)...IC CX23065
IC708	8-759-906-24	(E77ESD)...IC SN74LS624N
IC709	8-759-203-40	(E77ESD)...IC TC74HC393P
IC710	8-759-000-99	(E77ESD)...IC MC74HC74N
IC711	8-759-910-83	(E77ESD)...IC TL072ACP
IC712	8-759-918-71	(E77ESD)...IC CX23065
IC713	8-759-906-24	(E77ESD)...IC SN74LS624N
IC714	8-759-001-26	(E77ESD)...IC MC74HC112N
IC715	8-759-203-40	(E77ESD)...IC TC74HC393P
IC716	8-759-202-11	(E77ESD)...IC TC74HC00P
IC717	8-759-202-74	(E77ESD)...IC TC74HC04P
IC718	8-752-322-31	(E77ESD)...IC CXD1076P
IC719	8-759-939-35	(E77ESD)...IC CXD1088Q
IC720	8-759-000-99	(E77ESD)...IC MC74HC74N
IC721	8-759-000-99	(E77ESD)...IC MC74HC74N
IC801	8-759-938-46	(E77ESD)...IC PCM56P-JS
IC802	8-759-701-21	(E77ESD)...IC NJM5532D-D
IC803	8-759-701-21	(E77ESD)...IC NJM5532D-D
IC851	8-759-938-46	(E77ESD)...IC PCM56P-JS
IC852	8-759-701-21	(E77ESD)...IC NJM5532D-D
IC853	8-759-701-21	(E77ESD)...IC NJM5532D-D
IC951	8-759-601-43	(E77ESD)...IC M4066BP
IC952	8-759-801-61	(E77ESD)...IC LA7220
IC953	8-759-801-61	(E77ESD)...IC LA7220
J101	1-566-881-11	JACK, PIN 2P (PHONO)
J102	1-566-883-11	JACK, PIN 6P (TUNER/CD/AUX)
J103	1-566-883-11	JACK, PIN 6P (TAPE 1/TAPE 1 REC/TAPE 2 REC)
J104	1-566-883-11	JACK, PIN 6P (TAPE 2/VIDEO 1 OUT/VIDEO 2 IN)
J105	1-566-883-11	JACK, PIN 6P (VIDEO 2 IN/VIDEO 3 IN/VIDEO 2 OUT)
J106	1-566-882-11	JACK, PIN 4P (OUTPUT 1/2)
J107	1-566-892-11	(E77ESD)...JACK, PIN 2P (DAT ANALOGUE REC)
J108	1-566-892-11	JACK, PIN 2P (ADAPTOR OUT)
J109	1-566-892-11	JACK, PIN 2P (ADAPTOR IN)
J110	1-507-863-41	JACK, LARGE TYPE (HEADPHONES)
J501	1-566-893-11	JACK, PIN 2P (VIDEO 1 OUT/MONITOR VIDEO OUT)
J502	1-566-893-11	JACK, PIN 2P (VIDEO 1 IN/VIDEO 2 OUT)
J503	1-566-893-11	JACK, PIN 2P (VIDEO 3 IN/VIDEO 2 IN)
J551	1-566-846-11	(E77ESD)...CONNECTOR, (S) TERMINAL 4P (S VIDEO 1 IN)
J552	1-566-846-11	(E77ESD)...CONNECTOR, (S) TERMINAL 4P (S VIDEO 1 OUT)
J553	1-566-846-11	(E77ESD)...CONNECTOR, (S) TERMINAL 4P (S VIDEO 2 IN)
J554	1-566-846-11	(E77ESD)...CONNECTOR, (S) TERMINAL 4P (MONITOR S VIDEO OUT)
J701	*1-563-079-11	(E77ESD)...JACK, PIN 1P (DIGITAL IN 1)
J702	1-507-898-31	(E77ESD)...JACK, PIN 2P (DIGITAL IN 2/DAT DIGITAL IN)
J703	1-507-567-71	(E77ESD)...JACK, PIN 1P(DAT DIGITAL OUT)
L201	1-413-101-00	(G-AEP)...COIL, INPUT
L202	1-413-101-00	(G-AEP)...COIL, INPUT
L251	1-413-101-00	(G-AEP)...COIL, INPUT

The components identified by shading and mark **A** are critical for safety. Replace only with part number specified.

Les composants identifiés par une trame et une marque **A** sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

ELECTRICAL PARTS

Ref.No.	Part No.	Description
L252	1-413-101-00	(G-AEP)...COIL, INPUT
L401	▲ 1-424-026-11	COIL, LINE FILTER
L402	▲ 1-424-026-21	(E77ESD)...COIL, LINE FILTER
L601	▲ 1-424-026-11	COIL, LINE FILTER
L701	1-408-559-00	(E77ESD)...MICRO INDUCTOR 4.7UH
L702	1-408-559-00	(E77ESD)...MICRO INDUCTOR 4.7UH
L703	1-408-559-00	(E77ESD)...MICRO INDUCTOR 4.7UH
L704	1-408-559-00	(E77ESD)...MICRO INDUCTOR 4.7UH
L705	1-408-559-00	(E77ESD)...MICRO INDUCTOR 4.7UH
L706	1-408-559-00	(E77ESD)...MICRO INDUCTOR 4.7UH
L707	1-408-559-00	(E77ESD)...MICRO INDUCTOR 4.7UH
L708	1-408-559-00	(E77ESD)...MICRO INDUCTOR 4.7UH
L709	1-408-104-00	(E77ESD)...MICRO INDUCTOR 1MMH
L710	1-408-559-00	(E77ESD)...MICRO INDUCTOR 4.7UH
L711	1-408-559-00	(E77ESD)...MICRO INDUCTOR 4.7UH
L712	1-408-104-00	(E77ESD)...MICRO INDUCTOR 1MMH
L713	1-408-559-00	(E77ESD)...MICRO INDUCTOR 4.7UH
L714	1-408-559-00	(E77ESD)...MICRO INDUCTOR 4.7UH
L715	1-408-559-00	(E77ESD)...MICRO INDUCTOR 4.7UH
L716	1-408-104-00	(E77ESD)...MICRO INDUCTOR 1MMH
L717	1-408-559-00	(E77ESD)...MICRO INDUCTOR 4.7UH
L718	1-408-559-00	(E77ESD)...MICRO INDUCTOR 4.7UH
L719	1-408-080-00	(E77ESD)...MICRO INDUCTOR 100UH
L721	1-408-559-00	(E77ESD)...MICRO INDUCTOR 4.7UH
L722	1-408-559-00	(E77ESD)...MICRO INDUCTOR 4.7UH
L951	▲ 1-421-580-00	(US)...TRANSFORMER, LINE FILTER (LFT)
L951	▲ 1-421-960-11	(G-AEP)...TRANSFORMER, LINE FILTER
Q101	8-729-202-67	TRANSISTOR 2SK246-GR3
Q103	8-729-104-18	TRANSISTOR 2SC3514
Q104	8-765-640-10	TRANSISTOR 2SK244
Q105	▲ 8-729-113-82	TRANSISTOR 2SA1138
Q106	▲ 8-729-113-82	TRANSISTOR 2SA1138
Q107	▲ 8-729-167-62	TRANSISTOR 2SC2676
Q108	▲ 8-729-167-62	TRANSISTOR 2SC2676
Q109	▲ 8-729-104-18	TRANSISTOR 2SC3514
Q110	▲ 8-729-104-91	TRANSISTOR 2SA1383
Q151	8-729-202-67	TRANSISTOR 2SK246-GR3
Q153	8-729-104-18	TRANSISTOR 2SC3514
Q154	8-765-640-10	TRANSISTOR 2SK244
Q155	▲ 8-729-113-82	TRANSISTOR 2SA1138
Q156	▲ 8-729-113-82	TRANSISTOR 2SA1138
Q157	▲ 8-729-167-62	TRANSISTOR 2SC2676
Q158	▲ 8-729-167-62	TRANSISTOR 2SC2676
Q159	▲ 8-729-104-18	TRANSISTOR 2SC3514
Q160	▲ 8-729-104-91	TRANSISTOR 2SA1383
Q201	8-729-214-71	TRANSISTOR 2SK147
Q202	8-729-214-71	TRANSISTOR 2SK147
Q203	8-729-201-56	TRANSISTOR 2SK246-GR2
Q204	8-729-168-22	TRANSISTOR 2SC2682
Q205	8-729-194-57	TRANSISTOR 2SC945-P
Q251	8-729-214-71	TRANSISTOR 2SK147
Q252	8-729-214-71	TRANSISTOR 2SK147
Q253	8-729-201-56	TRANSISTOR 2SK246-GR2
Q254	8-729-168-22	TRANSISTOR 2SC2682
Q255	8-729-194-57	TRANSISTOR 2SC945-P
Q401	8-729-201-56	TRANSISTOR 2SK246-GR2
Q402	▲ 8-729-107-53	TRANSISTOR 2SC2275A

ELECTRICAL PARTS

Ref.No.	Part No.	Description
Q451	8-729-201-56	TRANSISTOR 2SK246-GR2
Q452	▲ 8-729-118-53	TRANSISTOR 2SA985-P
Q501	8-729-194-57	TRANSISTOR 2SC945-P
Q502	8-729-194-57	TRANSISTOR 2SC945-P
Q503	8-729-194-57	TRANSISTOR 2SC945-P
Q504	8-729-806-28	TRANSISTOR 2SC3402
Q601	8-729-806-28	TRANSISTOR 2SC3402
Q603	8-729-806-28	TRANSISTOR 2SC3402
Q604	8-729-154-82	TRANSISTOR 2SB548-R
Q691	8-729-600-27	TRANSISTOR 2SC634SP
Q692	8-729-806-28	TRANSISTOR 2SC3402
Q701	8-729-204-83	(E77ESD)...TRANSISTOR 2SA1048-GR
Q702	8-729-806-28	(E77ESD)...TRANSISTOR 2SC3402
Q703	8-729-159-01	(E77ESD)...TRANSISTOR 2SA1348
Q704	8-729-806-20	(E77ESD)...TRANSISTOR 2SA1345
Q705	8-729-159-01	(E77ESD)...TRANSISTOR 2SA1348
Q951	8-729-194-57	(E77ESD)...TRANSISTOR 2SC945-P
Q952	8-729-194-57	(E77ESD)...TRANSISTOR 2SC945-P
Q953	8-729-194-57	(E77ESD)...TRANSISTOR 2SC945-P
Q954	8-729-194-57	(E77ESD)...TRANSISTOR 2SC945-P
Q955	8-729-194-57	(E77ESD)...TRANSISTOR 2SC945-P
Q956	8-729-194-57	(E77ESD)...TRANSISTOR 2SC945-P
R101	1-247-713-11	CARBON 1K 5% 1/4W
R102	1-247-713-11	CARBON 1K 5% 1/4W
R103	1-247-713-11	CARBON 1K 5% 1/4W
R104	1-247-713-11	CARBON 1K 5% 1/4W
R105	1-247-713-11	(E77ESD)...CARBON 1K 5% 1/4W
R106	1-247-700-11	CARBON 100 5% 1/4W
R107	1-249-465-11	CARBON 47K 5% 1/4W
R108	1-247-721-11	CARBON 4.7K 5% 1/4W
R109	1-247-713-11	CARBON 1K 5% 1/4W
R110	1-246-545-00	CARBON 1M 5% 1/4W
R111	1-247-711-11	CARBON 680 5% 1/4W
R112	1-247-723-11	CARBON 6.8K 5% 1/4W
R113	1-247-725-11	CARBON 10K 5% 1/4W
R114	1-249-556-11	CARBON 1.5K 5% 1/4W
R115	1-249-895-11	CARBON 68 1% 1/4W
R116	1-249-895-11	CARBON 68 1% 1/4W
R117	1-247-706-11	CARBON 330 5% 1/4W
R118	1-249-556-11	CARBON 1.5K 5% 1/4W
R119	1-249-556-11	CARBON 1.5K 5% 1/4W
R120	▲ 1-247-711-11	CARBON 680 5% 1/4W
R121	1-247-146-00	CARBON 4.3K 5% 1/4W
R122	1-249-556-11	CARBON 1.5K 5% 1/4W
R123	1-249-556-11	CARBON 1.5K 5% 1/4W
R124	1-259-014-11	CARBON 4.7K 1% 1/2W
R125	▲ 1-249-641-11	CARBON 47 5% 1/2W
R126	1-249-641-11	CARBON 47 5% 1/2W
R127	1-249-641-11	CARBON 47 5% 1/2W
R128	▲ 1-249-641-11	CARBON 47 5% 1/2W
R129	1-249-641-11	CARBON 47 5% 1/2W
R130	1-249-604-11	CARBON 150K 5% 1/4W
R131	1-249-590-11	CARBON 39K 5% 1/4W
R132	1-249-590-11	CARBON 39K 5% 1/4W
R133	1-249-556-11	CARBON 1.5K 5% 1/4W
R134	1-247-700-11	CARBON 100 5% 1/4W
R135	1-249-469-11	CARBON 100K 5% 1/4W
R136	1-247-152-00	CARBON 8.2K 5% 1/4W

The components identified by shading and mark ▲ are critical for safety. Replace only with part number specified.

Les composants identifiés par une trame et une marque ▲ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

ELECTRICAL PARTS

Ref.No.	Part No.	Description	Value	Unit	Value	Unit
R137	1-259-025-11	CARBON	470	1%	1/2W	
R138	1-246-529-00	CARBON	220K	5%	1/4W	
R139	1-247-702-11	(G-AEP) ... CARBON	150	5%	1/4W	
R140	1-247-713-11	(G-AEP) ... CARBON	1K	5%	1/4W	
R141	1-247-713-11	CARBON	1K	5%	1/4W	
R142	1-249-595-11	CARBON	62K	5%	1/4W	
R151	1-247-713-11	CARBON	1K	5%	1/4W	
R152	1-247-713-11	CARBON	1K	5%	1/4W	
R153	1-247-713-11	CARBON	1K	5%	1/4W	
R154	1-247-713-11	CARBON	1K	5%	1/4W	
R155	1-247-713-11	(E77ESD) ... CARBON	1K	5%	1/4W	
R156	1-247-700-11	CARBON	100	5%	1/4W	
R157	1-249-465-11	CARBON	47K	5%	1/4W	
R158	1-247-721-11	CARBON	4.7K	5%	1/4W	
R159	1-247-713-11	CARBON	1K	5%	1/4W	
R160	1-246-545-00	CARBON	1M	5%	1/4W	
R161	1-247-711-11	CARBON	680	5%	1/4W	
R162	1-247-723-11	CARBON	6.8K	5%	1/4W	
R163	1-247-725-11	CARBON	10K	5%	1/4W	
R164	1-249-556-11	CARBON	1.5K	5%	1/4W	
R165	1-249-895-11	CARBON	68	1%	1/4W	
R166	1-249-895-11	CARBON	68	1%	1/4W	
R167	1-247-706-11	CARBON	330	5%	1/4W	
R168	1-249-556-11	CARBON	1.5K	5%	1/4W	
R169	1-249-556-11	CARBON	1.5K	5%	1/4W	
R170	▲ 1-247-711-11	CARBON	680	5%	1/4W	
R171	1-247-146-00	CARBON	4.3K	5%	1/4W	
R172	1-249-556-11	CARBON	1.5K	5%	1/4W	
R173	1-249-556-11	CARBON	1.5K	5%	1/4W	
R174	1-259-014-11	CARBON	4.7K	1%	1/2W	
R175	▲ 1-249-641-11	CARBON	47	5%	1/2W	
R176	1-249-641-11	CARBON	47	5%	1/2W	
R177	1-249-641-11	CARBON	47	5%	1/2W	
R178	▲ 1-249-641-11	CARBON	47	5%	1/2W	
R179	1-249-641-11	CARBON	47	5%	1/2W	
R180	1-249-604-11	CARBON	150K	5%	1/4W	
R181	1-249-590-11	CARBON	39K	5%	1/4W	
R182	1-249-590-11	CARBON	39K	5%	1/4W	
R183	1-249-556-11	CARBON	1.5K	5%	1/4W	
R184	1-247-700-11	CARBON	100	5%	1/4W	
R185	1-249-469-11	CARBON	100K	5%	1/4W	
R186	1-247-152-00	CARBON	8.2K	5%	1/4W	
R187	1-259-025-11	CARBON	470	1%	1/2W	
R188	1-246-529-00	CARBON	220K	5%	1/4W	
R189	1-247-713-11	(G-AEP) ... CARBON	1K	5%	1/4W	
R190	1-247-713-11	(G-AEP) ... CARBON	1K	5%	1/4W	
R191	1-247-713-11	CARBON	1K	5%	1/4W	
R192	1-249-595-11	CARBON	62K	5%	1/4W	
R201	1-247-706-11	CARBON	330	5%	1/4W	
R202	1-247-700-11	CARBON	100	5%	1/4W	
R203	1-247-713-11	CARBON	1K	5%	1/4W	
R204	1-249-465-11	CARBON	47K	5%	1/4W	
R205	1-247-721-11	CARBON	4.7K	5%	1/4W	
R206	1-247-704-11	CARBON	220	5%	1/4W	
R207	1-249-518-11	CARBON	39	5%	1/4W	
R208	1-247-708-11	CARBON	470	5%	1/4W	
R209	1-247-128-00	CARBON	750	5%	1/4W	
R210	1-247-700-11	CARBON	100	5%	1/4W	

ELECTRICAL PARTS

Ref.No.	Part No.	Description	Value	Unit	Value	Unit
R211	1-247-128-00	CARBON	750	5%	1/4W	
R212	1-249-874-11	CARBON	1M	1%	1/2W	
R214	1-249-844-11	CARBON	56K	1%	1/2W	
R216	1-249-818-11	CARBON	4.7K	1%	1/2W	
R217	1-249-777-11	CARBON	91	1%	1/2W	
R218	1-206-458-00	CARBON	6.2	5%	1/3W	
R219	1-247-704-11	CARBON	220	5%	1/4W	
R220	1-247-706-11	(G-AEP) ... CARBON	330	5%	1/4W	
R221	1-247-706-11	(G-AEP) ... CARBON	330	5%	1/4W	
R251	1-247-706-11	CARBON	330	5%	1/4W	
R252	1-247-700-11	CARBON	100	5%	1/4W	
R253	1-247-713-11	CARBON	1K	5%	1/4W	
R254	1-249-465-11	CARBON	47K	5%	1/4W	
R255	1-247-721-11	CARBON	4.7K	5%	1/4W	
R256	1-247-704-11	CARBON	220	5%	1/4W	
R257	1-249-518-11	CARBON	39	5%	1/4W	
R258	1-247-708-11	CARBON	470	5%	1/4W	
R259	1-247-128-00	CARBON	750	5%	1/4W	
R260	1-247-700-11	CARBON	100	5%	1/4W	
R261	1-247-128-00	CARBON	750	5%	1/4W	
R262	1-249-874-11	CARBON	1M	1%	1/2W	
R264	1-249-844-11	CARBON	56K	1%	1/2W	
R266	1-249-818-11	CARBON	4.7K	1%	1/2W	
R267	1-249-777-11	CARBON	91	1%	1/2W	
R268	1-206-458-00	CARBON	6.2	5%	1/3W	
R269	1-247-704-11	CARBON	220	5%	1/4W	
R291	▲ 1-247-735-11	CARBON	47	5%	1/2W	F
R292	▲ 1-247-735-11	CARBON	47	5%	1/2W	F
R270	1-247-706-11	(G-AEP) ... CARBON	330	5%	1/4W	
R271	1-247-706-11	(G-AEP) ... CARBON	330	5%	1/4W	
R301	1-202-727-00	CARBON	4.7M	5%	1/3W	
R302	1-202-727-00	CARBON	4.7M	5%	1/3W	
R303	1-247-725-11	CARBON	10K	5%	1/4W	
R304	1-202-727-00	CARBON	4.7M	5%	1/3W	
R305	1-202-727-00	CARBON	4.7M	5%	1/3W	
R306	1-249-466-11	CARBON	56K	5%	1/4W	
R307	1-202-727-00	CARBON	4.7M	5%	1/3W	
R308	1-247-722-11	CARBON	5.6K	5%	1/4W	
R309	1-247-717-11	CARBON	2.2K	5%	1/4W	
R310	1-202-727-00	CARBON	4.7M	5%	1/3W	
R351	1-202-727-00	CARBON	4.7M	5%	1/3W	
R352	1-202-727-00	CARBON	4.7M	5%	1/3W	
R353	1-247-725-11	CARBON	10K	5%	1/4W	
R354	1-202-727-00	CARBON	4.7M	5%	1/3W	
R355	1-202-727-00	CARBON	4.7M	5%	1/3W	
R356	1-249-466-11	CARBON	56K	5%	1/4W	
R357	1-202-727-00	CARBON	4.7M	5%	1/3W	
R358	1-247-722-11	CARBON	5.6K	5%	1/4W	
R359	1-247-717-11	CARBON	2.2K	5%	1/4W	
R360	1-202-727-00	CARBON	4.7M	5%	1/3W	
R402	1-247-719-11	CARBON	3.3K	5%	1/4W	
R403	1-247-704-11	CARBON	220	5%	1/4W	
R404	1-249-460-11	CARBON	15K	5%	1/4W	
R405	1-247-719-11	CARBON	3.3K	5%	1/4W	
R452	1-247-719-11	CARBON	3.3K	5%	1/4W	
R453	1-247-704-11	CARBON	220	5%	1/4W	
R454	1-249-460-11	CARBON	15K	5%	1/4W	

The components identified by shading and mark A are critical for safety. Replace only with part number specified.

Les composants identifiés par une trame et une marque A sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

ELECTRICAL PARTS

Ref.No.	Part No.	Description	Value	Tolerance	Power	Mark
R491	1-247-694-11	CARBON	33	5%	1/4W	F
R501	1-215-394-00	CARBON	75	5%	1/4W	
R502	1-249-429-11	CARBON	10K	5%	1/4W	
R503	1-215-394-00	CARBON	75	5%	1/4W	
R504	1-249-429-11	CARBON	10K	5%	1/4W	
R505	1-249-401-11	CARBON	47	5%	1/4W	
R506	1-249-429-11	CARBON	10K	5%	1/4W	
R507	1-249-414-11	CARBON	560	5%	1/4W	
R508	1-215-394-00	CARBON	75	5%	1/4W	
R509	1-249-429-11	CARBON	10K	5%	1/4W	
R510	1-249-401-11	CARBON	47	5%	1/4W	
R511	1-249-429-11	CARBON	10K	5%	1/4W	
R512	1-249-414-11	CARBON	560	5%	1/4W	
R513	1-249-401-11	CARBON	47	5%	1/4W	
R514	1-249-429-11	CARBON	10K	5%	1/4W	
R515	1-249-414-11	CARBON	560	5%	1/4W	
R516	1-249-440-11	CARBON	82K	5%	1/4W	
R517	1-249-435-11	CARBON	33K	5%	1/4W	
R518	1-249-416-11	CARBON	820	5%	1/4W	
R519	1-249-423-11	CARBON	3.3K	5%	1/4W	
R520	1-247-849-00	CARBON	5.6K	5%	1/4W	
R521	1-249-423-11	CARBON	3.3K	5%	1/4W	
R522	1-247-887-00	CARBON	220K	5%	1/4W	
R523	1-249-429-11	CARBON	10K	5%	1/4W	
R524	1-249-429-11	CARBON	10K	5%	1/4W	
R526	1-249-429-11	CARBON	10K	5%	1/4W	
R527	1-249-429-11	CARBON	10K	5%	1/4W	
R528	1-249-429-11	CARBON	10K	5%	1/4W	
R601	1-249-430-11	CARBON	12K	5%	1/4W	
R605	1-249-437-11	CARBON	47K	5%	1/4W	
R606	1-247-710-11	CARBON	560	5%	1/4W	
R607	1-249-405-11	CARBON	100	5%	1/4W	
R608	1-249-417-11	CARBON	1K	5%	1/4W	
R609	1-249-417-11	CARBON	1K	5%	1/4W	
R610	1-249-417-11	CARBON	1K	5%	1/4W	
R611	1-249-417-11	CARBON	1K	5%	1/4W	
R612	1-249-417-11	CARBON	1K	5%	1/4W	
R613	1-249-417-11	CARBON	1K	5%	1/4W	
R614	1-249-417-11	CARBON	1K	5%	1/4W	
R615	1-249-417-11	CARBON	1K	5%	1/4W	
R616	1-249-417-11	CARBON	1K	5%	1/4W	
R617	1-249-433-11	CARBON	22K	5%	1/4W	
R618	1-249-433-11	CARBON	22K	5%	1/4W	
R619	1-249-433-11	CARBON	22K	5%	1/4W	
R620	1-249-433-11	CARBON	22K	5%	1/4W	
R621	1-249-441-11	CARBON	100K	5%	1/4W	
R622	1-249-441-11	CARBON	100K	5%	1/4W	
R623	1-249-441-11	CARBON	100K	5%	1/4W	
R624	1-249-441-11	CARBON	100K	5%	1/4W	
R625	1-249-417-11	CARBON	1K	5%	1/4W	
R626	1-249-417-11	CARBON	1K	5%	1/4W	
R627	1-249-417-11	CARBON	1K	5%	1/4W	
R628	1-249-417-11	CARBON	1K	5%	1/4W	
R629	1-249-407-11	CARBON	150	5%	1/4W	
R630	1-249-417-11	CARBON	1K	5%	1/4W	
R631	1-249-433-11	CARBON	22K	5%	1/4W	
R632	1-249-417-11	CARBON	1K	5%	1/4W	

ELECTRICAL PARTS

R634	1-249-417-11	(E77ESD)...CARBON	1K	5%	1/4W	
R635	1-249-417-11	(E77ESD)...CARBON	1K	5%	1/4W	
R636	1-249-417-11	(E77ESD)...CARBON	1K	5%	1/4W	
R637	1-249-417-11	(E77ESD)...CARBON	1K	5%	1/4W	
R638	1-249-417-11	(E77ESD)...CARBON	1K	5%	1/4W	
R639	1-249-417-11	(E77ESD)...CARBON	1K	5%	1/4W	
R640	1-247-118-00	(E77ESD)...CARBON	300	5%	1/4W	
R641	1-247-118-00	(E77ESD)...CARBON	300	5%	1/4W	
R642	1-247-118-00	CARBON	300	5%	1/4W	
R643	1-247-118-00	CARBON	300	5%	1/4W	
R644	1-247-118-00	CARBON	300	5%	1/4W	
R645	1-247-118-00	CARBON	300	5%	1/4W	
R646	1-247-118-00	CARBON	300	5%	1/4W	
R647	1-247-118-00	CARBON	300	5%	1/4W	
R648	1-247-118-00	CARBON	300	5%	1/4W	
R649	1-247-118-00	CARBON	300	5%	1/4W	
R650	1-247-118-00	CARBON	300	5%	1/4W	
R651	1-247-118-00	CARBON	300	5%	1/4W	
R652	1-247-118-00	CARBON	300	5%	1/4W	
R653	1-247-118-00	CARBON	300	5%	1/4W	
R654	1-247-118-00	(E77ESD)...CARBON	300	5%	1/4W	
R655	1-247-707-11	(E77ESD)...CARBON	390	5%	1/4W	
R656	1-247-707-11	(E77ESD)...CARBON	390	5%	1/4W	
R657	1-247-707-11	(E77ESD)...CARBON	390	5%	1/4W	
R658	1-249-429-11	CARBON	10K	5%	1/4W	
R659	1-249-429-11	CARBON	10K	5%	1/4W	
R660	1-249-433-11	CARBON	22K	5%	1/4W	
R661	1-249-433-11	CARBON	22K	5%	1/4W	
R662	1-249-417-11	CARBON	1K	5%	1/4W	
R663	1-249-417-11	CARBON	1K	5%	1/4W	
R691	1-249-429-11	CARBON	10K	5%	1/4W	
R692	1-249-429-11	CARBON	10K	5%	1/4W	
R693	1-249-425-11	CARBON	4.7K	5%	1/4W	
R694	1-249-393-11	CARBON	10	5%	1/4W	
R701	1-215-394-00	(E77ESD)...CARBON	75	5%	1/4W	
R703	1-215-394-00	(E77ESD)...CARBON	75	5%	1/4W	
R705	1-215-394-00	(E77ESD)...CARBON	75	5%	1/4W	
R707	1-249-429-11	(E77ESD)...CARBON	10K	5%	1/4W	
R708	1-249-419-11	(E77ESD)...CARBON	1.5K	5%	1/4W	
R709	1-215-432-00	(E77ESD)...CARBON	3K	5%	1/4W	
R710	1-215-452-00	(E77ESD)...CARBON	20K	5%	1/4W	
R711	1-215-442-00	(E77ESD)...CARBON	7.5K	5%	1/4W	
R712	1-249-429-11	(E77ESD)...CARBON	10K	5%	1/4W	
R713	1-249-425-11	(E77ESD)...CARBON	4.7K	5%	1/4W	
R714	1-247-723-11	(E77ESD)...CARBON	6.8K	5%	1/4W	
R715	1-249-417-11	(E77ESD)...CARBON	1K	5%	1/4W	
R716	1-249-429-11	(E77ESD)...CARBON	10K	5%	1/4W	
R717	1-249-433-11	(E77ESD)...CARBON	22K	5%	1/4W	
R718	1-249-433-11	(E77ESD)...CARBON	22K	5%	1/4W	
R719	1-249-433-11	(E77ESD)...CARBON	22K	5%	1/4W	
R720	1-249-429-11	(E77ESD)...CARBON	10K	5%	1/4W	
R721	1-249-425-11	(E77ESD)...CARBON	4.7K	5%	1/4W	
R722	1-249-423-11	(E77ESD)...CARBON	3.3K	5%	1/4W	
R723	1-249-432-11	(E77ESD)...CARBON	18K	5%	1/4W	
R725	1-215-491-00	(E77ESD)...CARBON	820K	5%	1/4W	
R726	1-249-423-11	(E77ESD)...CARBON	3.3K	5%	1/4W	
R727	1-249-437-11	(E77ESD)...CARBON	47K	5%	1/4W	

The components identified by shading and mark  are critical for safety. Replace only with part number specified.

Les composants identifiés par une trame et une marque  sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

ELECTRICAL PARTSRef.No. Part No. Description

R728	1-215-440-00	(E77ESD)...CARBON	6.2K	5%	1/4W
R729	1-215-448-00	(E77ESD)...CARBON	13K	5%	1/4W
R730	1-249-429-11	(E77ESD)...CARBON	10K	5%	1/4W
R731	1-215-476-00	(E77ESD)...CARBON	200K	5%	1/4W
R732	1-215-476-00	(E77ESD)...CARBON	200K	5%	1/4W
R733	1-249-429-11	(E77ESD)...CARBON	10K	5%	1/4W
R734	1-249-429-11	(E77ESD)...CARBON	10K	5%	1/4W
R735	1-249-435-11	(E77ESD)...CARBON	33K	5%	1/4W
R736	1-249-413-11	(E77ESD)...CARBON	470	5%	1/4W
R737	1-249-407-11	(E77ESD)...CARBON	150	5%	1/4W
R791	1-215-398-00	(E77ESD)...CARBON	110	5%	1/4W
R792	1-215-394-00	(E77ESD)...CARBON	75	5%	1/4W
R793	1-215-452-00	(E77ESD)...CARBON	20K	5%	1/4W
R794	1-215-452-00	(E77ESD)...CARBON	20K	5%	1/4W
R795	1-249-433-11	(E77ESD)...CARBON	22K	5%	1/4W
R796	1-249-433-11	(E77ESD)...CARBON	22K	5%	1/4W
R797	1-215-452-00	(E77ESD)...CARBON	20K	5%	1/4W
R798	1-249-433-11	(E77ESD)...CARBON	22K	5%	1/4W
R799	1-249-437-11	(E77ESD)...CARBON	47K	5%	1/4W
R801	1-247-757-11	(E77ESD)...CARBON	2.7K	5%	1/2W
R802	1-247-757-11	(E77ESD)...CARBON	2.7K	5%	1/2W
R803	1-247-716-11	(E77ESD)...CARBON	1.8K	5%	1/4W
R804	1-246-545-00	(E77ESD)...CARBON	1M	5%	1/4W
R805	1-249-679-11	(E77ESD)...CARBON	1.8K	5%	1/2W
R806	1-247-716-11	(E77ESD)...CARBON	1.8K	5%	1/4W
R807	1-247-716-11	(E77ESD)...CARBON	1.8K	5%	1/4W
R808	1-247-716-11	(E77ESD)...CARBON	1.8K	5%	1/4W
R809	1-247-739-11	(E77ESD)...CARBON	100	5%	1/2W
R810	1-249-616-11	(E77ESD)...CARBON	470K	5%	1/4W
R851	1-247-757-11	(E77ESD)...CARBON	2.7K	5%	1/2W
R852	1-247-757-11	(E77ESD)...CARBON	2.7K	5%	1/2W
R853	1-247-716-11	(E77ESD)...CARBON	1.8K	5%	1/4W
R854	1-246-545-00	(E77ESD)...CARBON	1M	5%	1/4W
R855	1-249-679-11	(E77ESD)...CARBON	1.8K	5%	1/2W
R856	1-247-716-11	(E77ESD)...CARBON	1.8K	5%	1/4W
R857	1-247-716-11	(E77ESD)...CARBON	1.8K	5%	1/4W
R858	1-247-716-11	(E77ESD)...CARBON	1.8K	5%	1/4W
R859	1-247-739-11	(E77ESD)...CARBON	100	5%	1/2W
R860	1-249-616-11	(E77ESD)...CARBON	470K	5%	1/4W
R951	1-215-394-00	(E77ESD)...CARBON	75	5%	1/4W
R952	1-249-429-11	(E77ESD)...CARBON	10K	5%	1/4W
R953	1-249-429-11	(E77ESD)...CARBON	10K	5%	1/4W
R954	1-215-394-00	(E77ESD)...CARBON	75	5%	1/4W
R955	1-249-429-11	(E77ESD)...CARBON	10K	5%	1/4W
R956	1-249-429-11	(E77ESD)...CARBON	10K	5%	1/4W
R957	1-249-401-11	(E77ESD)...CARBON	47	5%	1/4W
R958	1-249-429-11	(E77ESD)...CARBON	10K	5%	1/4W
R959	1-249-414-11	(E77ESD)...CARBON	560	5%	1/4W
R960	1-249-401-11	(E77ESD)...CARBON	47	5%	1/4W
R961	1-249-429-11	(E77ESD)...CARBON	10K	5%	1/4W
R962	1-249-414-11	(E77ESD)...CARBON	560	5%	1/4W
R963	1-215-394-00	(E77ESD)...CARBON	75	5%	1/4W
R964	1-249-429-11	(E77ESD)...CARBON	10K	5%	1/4W
R965	1-249-429-11	(E77ESD)...CARBON	10K	5%	1/4W
R966	1-215-394-00	(E77ESD)...CARBON	75	5%	1/4W
R967	1-249-429-11	(E77ESD)...CARBON	10K	5%	1/4W
R968	1-249-429-11	(E77ESD)...CARBON	10K	5%	1/4W

ELECTRICAL PARTSRef.No. Part No. Description

R969	1-249-401-11	(E77ESD)...CARBON	47	5%	1/4W
R970	1-249-429-11	(E77ESD)...CARBON	10K	5%	1/4W
R971	1-249-414-11	(E77ESD)...CARBON	560	5%	1/4W
R972	1-249-401-11	(E77ESD)...CARBON	47	5%	1/4W
R973	1-249-429-11	(E77ESD)...CARBON	10K	5%	1/4W
R974	1-249-414-11	(E77ESD)...CARBON	560	5%	1/4W
R975	1-249-440-11	(E77ESD)...CARBON	82K	5%	1/4W
R976	1-249-435-11	(E77ESD)...CARBON	33K	5%	1/4W
R977	1-249-416-11	(E77ESD)...CARBON	820	5%	1/4W
R978	1-249-423-11	(E77ESD)...CARBON	3.3K	5%	1/4W
R979	1-247-849-00	(E77ESD)...CARBON	5.6K	5%	1/4W
R980	1-249-423-11	(E77ESD)...CARBON	3.3K	5%	1/4W
R981	1-249-440-11	(E77ESD)...CARBON	82K	5%	1/4W
R982	1-249-435-11	(E77ESD)...CARBON	33K	5%	1/4W
R983	1-249-416-11	(E77ESD)...CARBON	820	5%	1/4W
R984	1-249-423-11	(E77ESD)...CARBON	3.3K	5%	1/4W
R985	1-247-849-00	(E77ESD)...CARBON	5.6K	5%	1/4W
R986	1-249-423-11	(E77ESD)...CARBON	3.3K	5%	1/4W
RV101	1-237-851-11	RES, VAR, CARBON	120K/120K	(ATTENUATOR)	
RV301	1-237-853-11	RES, VAR, CARBON	150K/150K	(BALANCE)	
RV302	1-237-854-11	RES, VAR, CARBON	1M ² /500K ²	(BASS)	
RV303	1-237-852-11	RES, VAR, CARBON	250K/250K	(TREBLE)	
RV701	1-224-252-XX	(E77ESD)...RES, ADJ, METAL GLAZE	10K		
RY101	1-515-614-11	(E77ESD)...RELAY			
RY102	1-515-614-11	RELAY			
RY103	1-515-614-11	RELAY			
RY104	1-515-614-11	RELAY			
RY105	1-515-614-11	RELAY			
RY106	1-515-614-11	RELAY			
RY107	1-515-614-11	RELAY			
RY108	1-515-614-11	RELAY			
RY109	1-515-614-11	RELAY			
RY110	1-515-614-11	RELAY			
RY111	1-515-614-11	RELAY			
RY112	1-515-614-11	RELAY			
RY113	1-515-614-11	RELAY			
RY114	1-515-614-11	RELAY			
RY115	1-515-614-11	RELAY			
RY116	1-515-614-11	RELAY			
RY117	1-515-614-11	RELAY			
RY118	1-515-614-11	RELAY			
RY119	1-515-614-11	(E77ESD)...RELAY			
RY601	1-515-493-00	RELAY			
RY701	1-515-495-00	(E77ESD)...RELAY			
RY702	1-515-622-11	(E77ESD)...RELAY			
S101	1-554-879-11	SWITCH, SLIDE (AUDIO REC SELECTOR)			
S102	1-571-243-11	SWITCH, SLIDE (AUDIO REC SELECTOR)			
S103	1-571-240-11	SWITCH, ROTARY (OUTPUT)			
S201	1-554-019-00	SWITCH, SLIDE (REMOTE TYPE)(CARTRIDGE)			
S301	1-571-242-11	SWITCH, PUSH (2 KEY)(SUBSONIC, MODE)			
S302	1-570-029-11	SWITCH, PUSH (1 KEY)(TURNOVER)			
S303	1-570-029-11	SWITCH, PUSH (1 KEY)(TURNOVER)			
S601	1-554-303-21	(E77ESD)...SWITCH, KEY BOARD(DIGITAL 1)			
S602	1-554-303-21	SWITCH, KEY BOARD (DIGITAL 2)			
S603	1-554-303-21	SWITCH, KEY BOARD (PHONO)			
S604	1-554-303-21	SWITCH, KEY BOARD (TUNER)			
S605	1-554-303-21	SWITCH, KEY BOARD (CD)			

ELECTRICAL PARTS

Ref.No.	Part No.	Description
S606	1-554-303-21	SWITCH, KEY BOARD (AUX)
S607	1-554-303-21	SWITCH, KEY BOARD (TAPE 1)
S608	1-554-303-21	SWITCH, KEY BOARD (TAPE 2)
S609	1-554-303-21	SWITCH, KEY BOARD (VIDEO 3)
S610	1-554-303-21	SWITCH, KEY BOARD (VIDEO 2)
S611	1-554-303-21	SWITCH, KEY BOARD (VIDEO 1)
S612	1-554-303-21	SWITCH, KEY BOARD (ADAPTOR)
S613	1-554-303-21	(E77ESD)...SWITCH, KEY BOARD (DAT)
S614	1-554-303-21	SWITCH, KEY BOARD (SOURCE DIRECT)
S615	1-554-303-21	SWITCH, KEY BOARD (MUTING -20dB)
S616	1-571-241-11	SWITCH, PUSH (1 KEY)(POWER)
S951	Δ.1-570-046-21	(AEP,UK,E)...SWITCH, VOLTAGE CHANGE (VOLTAGE SELECTOR)
T701	1-459-587-11	(E77ESD)...COIL (WITH CORE)
T951	Δ.1-449-019-11	(US,Canadian)...TRANSFORMER, POWER
T951	Δ.1-449-020-11	(AEP,G-AEP,UK,E)...TRANSFORMER, POWER
T952	Δ.1-449-014-11	TRANSFORMER, POWER
TB101	*1-508-880-00	BASE POST, MCD CONNECTOR 6P
TB102	*1-560-200-00	BASE POST, MCD CONNECTOR 2P
TB103	*1-560-200-00	BASE POST, MCD CONNECTOR 2P
TB104	*1-560-200-00	BASE POST, MCD CONNECTOR 2P
TB105	*1-560-200-00	BASE POST, MCD CONNECTOR 2P
TB106	*1-560-200-00	BASE POST, MCD CONNECTOR 2P
TB107	*1-560-200-00	BASE POST, MCD CONNECTOR 2P
TB108	*1-560-200-00	BASE POST, MCD CONNECTOR 2P
TB109	*1-560-200-00	BASE POST, MCD CONNECTOR 2P
TB401	*1-535-115-00	TERMINAL 2P
TB402	*1-535-116-00	TERMINAL 3P
TB403	*1-535-116-00	TERMINAL 3P
TB601	*1-535-139-00	BASE POST 19MM (10MM PITCH) 2P
TB602	*1-535-140-00	(US,Canadian,AEP,UK,E) ...BASE POST 19MM(10MM PITCH) 3P
TB602	*1-535-141-00	(G-AEP)...BASE POST 19MM(10MM PITCH) 4P
TB604	*1-535-115-00	(US,Canadian,G-AEP)...TERMINAL 2P
TH701	1-800-200-00	(E77ESD)...THERMISTOR S-3K
X601	1-567-160-00	OSCILLATOR, CERAMIC (4.19MHz)

ACCESSORY & PACKING MATERIAL

Part No.	Description
1-463-901-11	(E77ES)...COMMANDER, REMOTE (RM-177)
1-463-902-11	(AEP,G-AEP,UK)...COMMANDER, REMOTE (RM-177D)
1-463-953-11	(US,Canadian)...COMMANDER, REMOTE (RM-E7)
1-551-315-00	CORD, CONNECTION (RK-112)
1-557-817-11	(E77ESD)...CORD, CONNECTION
*3-697-712-01	SHEET, PROTECTION
3-703-450-01	INSTRUCTION
3-769-377-11	MANUAL, INSTRUCTION
4-922-201-01	(E77ES)...INDIVIDUAL CARTON
4-922-201-11	(E77ESD)...INDIVIDUAL CARTON
4-922-202-01	CUSHION